






Model SL-145

Parts and Operations Manual




Hoist Serial Number: _____



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	90P07	OPR & SERV MANUAL		
2	2	90P08	HOIST-BODY SPEC		
3	ONE	90P09	HYD OIL SPEC		
4	ONE	90P10	HYD OIL FLAMMABLE		
5	2	90P11	HOIST FALLING		
6	ONE	90P12	LEVER CONTROL		
7	ONE	90P13	SAFETY INSTRUCTIONS		
8	2	90P14	SWAPLOADER - JIB		
9	4	90P67	SL-145		
10	ONE	90P18	RELIEF VALVE		
11	ONE	90P78	HIGH-PRESSURE FLUID		
12	2	91P06	LUBRICATION POINTS		
				TOTAL	





WARRANTY REGISTRATION FORM

HOIST INFORMATION

MODEL: _____ Signature: _____
SERIAL NO.: _____ Date Installed: _____
Date Inspected: _____

VEHICLE INFORMATION

Manufacturer: _____
Model: _____
Year: _____
Wheel Base: _____
VIN: _____
PTO Type: _____
PTO Ratio: _____

DISTRIBUTOR INFORMATION

Company Name: _____
Sales Person's Name: _____
Address: _____
City, State & Zip: _____
Phone: _____

The unit has been checked and serviced according to SwapLoader's Pre-delivery Check List. The proper mechanical operation of the unit as described in the written Parts & Operations Manual, provided by SwapLoader USA, Ltd., has been discussed with the customer.

CUSTOMER INFORMATION

Company Name: _____
Contact Name (owner): _____
Address: _____
City, State & Zip: _____
Phone: _____
Customer's Signature: _____

Waste / Recycling: <input type="checkbox"/>	Municipal: <input type="checkbox"/>	Fire Dept.: <input type="checkbox"/>
Construction / Contractor: <input type="checkbox"/>	Tree / Nursery: <input type="checkbox"/>	Lumber Yard: <input type="checkbox"/>
Landscaping: <input type="checkbox"/>	Roofing: <input type="checkbox"/>	Other: _____

COMPLETE & SAVE TO YOUR COMPUTER. RETAIN A COPY FOR YOUR FILES.
ONCE COMPLETE, FAX (515-313-4426) OR EMAIL (sales@swaploader.net) A COPY BACK TO SWAPLOADER!

1800 NE Broadway Ave., Des Moines, IA 50313 • www.swaploader.com • Toll Free: 888-767-8000



PRE-DELIVERY CHECK LIST



INSPECTOR'S INFORMATION

Inspected By: _____ Signature: _____
Distributor: _____ Date Installed: _____
Customer: _____ Date Inspected: _____

I. COMPONENT INFORMATION

Hoist Model: _____
Hoist Serial No.: _____
Chassis VIN: _____
Chassis Make & Model: _____
Chassis GVWR: _____
Chassis CA / CT: _____
After Frame: _____

Distance from rear of cab to the centerline of rear axle/tandem.
Distance from centerline of rear axle/tandem to rear of hoist.



PTO Make: _____
PTO Model: _____
PTO Serial No.: _____
PTO % of Engine RPM: _____

Hyd. Pump Make: _____
Hyd. Pump Model: _____
Hyd. Pump Serial No.: _____

II. INSTALLATION TO CHASSIS

Were there any problems installing the hoist to the truck chassis? ☐ YES ☐ NO

If yes, please describe: _____

- ☐ All bolts checked for proper tightness.
- ☐ Please include photos of the hoist installed on the truck chassis. Be sure to include at least one photo from each side of the chassis/hoist.



III. CONTROLS

- ☐ Controls easy to operate from driver's seat.
- ☐ Movement of controls correct, per installation instructions.

IV. HYDRAULIC INSTALLATION

- ☐ Correct hydraulic oil level in reservoir, per installation instructions.
- ☐ Inspected for leaks.

Any abnormal noise during hoist operation? ☐ YES ☐ NO

If yes, please describe: _____

With engine operating @ 1,000 RPM, record the following information:

Cycle time for dump mode: _____ Seconds Up _____ Seconds Down
Cycle time for load/unload mode: _____ Seconds to Unload _____ Seconds to Load
Filter pressure: _____ PSI
Main pressure, controls in neutral: _____ PSI
Main relief pressure when extending
jib cylinder (bottomed out): _____ PSI
Main relief pressure when extending
lift cylinders (bottomed out): _____ PSI

NOTE: Connect pressure gauge to fitting provided on the inlet section of the Hydraulic Control Valve (Ref. Part No. 10P37, fitting on Hydraulic Pump Circuit Drawing found in the Parts List section of the Hoist's Parts & Operations Manual).

V. OPERATION

- ☐ Jib operates freely in both directions.
- ☐ Jib cannot be extended or retracted when raised in dump position or when pivot joint is tilted in unload position. Both safety hooks are fully engaged when jib is extended.
- ☐ Parts & Operations Manual is in the cab.
- ☐ Lubricate sliding jib and all grease zerks per installation instructions.

VI. DECALS

- ☐ All safety decals and product decals installed per enclosed decal drawings (found attached to the inside of the hoist's Parts & Operations Manual cover or at the back of the Parts List section in the Manual).

Additional Comments: _____

COMPLETE & SAVE TO YOUR COMPUTER. RETAIN A COPY FOR YOUR FILES.
ONCE COMPLETE, FAX (515-313-4426) OR EMAIL (sales@swaploader.net) A COPY BACK TO SWAPLOADER!

1800 NE Broadway Ave., Des Moines, IA 50313 • www.swaploader.com • Toll Free: 888-767-8000

TABLE OF CONTENTS

I. INTRODUCTION

Letter to Customer
Warranty Statement
Safety Suggestions

II. INSTALLATION

Initial Inspection
Hoist Installation
Controls Installation
Hydraulic Tank Installation
P.T.O. Selection
Pump Installation
Start Up Procedure
100 Series Subframe Dimensions
Accessory Installation
 Bumper Assembly
 Bumper Assembly, w/ Extension
 Cab Guard Assembly
 Container Variability System – (C.V.S.)
 Fender Assembly, Single Axle
 Rear Light Bar Assembly
 Roller & Roller Mount
 Toolbox Assembly

III. OPERATION

Loading a Container
Dumping a Container
Placing a Container on the Ground

IV. MAINTENANCE

Weekly Service (50 Operations)
Monthly Service (200 Operations)
Yearly Service
Lubrication Diagram
Hydraulic Oil Specifications
Hydraulic Filter Interchange
General Maintenance Parts List
Replacement Bearing List
Mast Lock (Safety Latch) Inspection &
 Adjustment Instructions
Pressure Check Instructions

V. PARTS LIST

Base Assembly
Mainframe Subassembly
Rear Pivot Subassembly
Telescopic Jib Subassembly
Mast Lock (Safety Latch) Assembly
Hoist Installation Kit Assembly
Manual Control Assembly, 2 Section
Hyd. Sub-Ass'y – Base Cylinder Circuit
Hyd. Sub-Ass'y – Chassis-Tank Circuit
Hydraulic Sub-Assembly – Pump Circuit
Decal Assembly

VI. OPTIONS

EHV Kit
 Installation Instructions
 Hoist Installation Kit
 Hydraulic Sub-Ass'y – Base Circuit
 Electric Over Hydraulic Valve Kit
 Electric Over Hydraulic Valve Hose Kit

INTRODUCTION

SWAPLOADER U.S.A., LTD.

TO THE CUSTOMER

Your new SwapLoader Hoist was carefully designed and manufactured to give years of dependable service. To keep it operating efficiently, read the instructions in this manual thoroughly. It contains detailed descriptions and instructions for the efficient operation and maintenance of your SwapLoader. Each section is clearly identified so you can easily find the information that you need. Read the Table of Contents to learn where each section is located. All instructions are recommended procedures only.



Throughout this manual you will come across "**Dangers**," "**Warnings**," or "**Cautions**" which will be carried out in bold type and preceded by the symbol as indicated to the left. Be certain to carefully read the message that follows to avoid the possibility of personal injury or machine damage.

Record your SwapLoader Hoist serial number in the appropriate space provided on the title page. Your SwapLoader dealer needs this information to give you prompt, efficient service when you order parts. It pays to rely on an authorized SwapLoader Distributor for your service needs. For the location of the Distributor nearest you, contact SwapLoader.

NOTE: It is SwapLoader's policy to constantly strive to improve SwapLoader products. The information, specifications, and illustrations in this publication are based on the information in effect at the time of approval for printing and publishing. SwapLoader therefore reserves the right to make changes in design and improvements whenever it is believed the efficiency of the unit will be improved without incurring any obligations to incorporate such improvements in any unit which has been shipped or is in service. It is recommended that users contact an authorized SwapLoader Distributor for the latest revisions.

SWAPLOADER, U.S.A., LTD.
1800 N.E. BROADWAY, DES MOINES, IOWA 50313

LIMITED WARRANTY STATEMENT

Effective September 1, 2009

SwapLoader U.S.A., Ltd., (SwapLoader), warrants to the original purchaser of any new SwapLoader product sold by an authorized SwapLoader distributor or service center, that such products are free of defects in material and workmanship. All SwapLoader products with an original factory invoice date of September 1, 2009 or later qualify for warranty as defined in this Limited Warranty Statement.

- Repair or replacement of parts on SwapLoader products are covered under warranty for forty-eight (48) months from date of Retail Sale by an authorized SwapLoader Distributor or service center, subject to any applicable federal, state or local taxes, and not to extend beyond sixty (60) months from the original factory invoice date. SwapLoader will, at its discretion, either repair the defective parts or replace them with equivalent parts, subject to the conditions below.
- Labor charges authorized by the SwapLoader Warranty Department are covered under warranty for a period of twelve (12) months from the date of Retail Sale by an authorized SwapLoader Distributor or service center, and not to extend beyond twenty-four (24) months labor from the original factory invoice date.
- Warranty Registration Card must be returned within 15 days of Retail Sale of SwapLoader hoist to SwapLoader, Des Moines, Iowa. If unit has not been registered, then the warranty start date will revert to the original factory invoice date. Warranty Registration is the ultimate responsibility of the owner and may be accomplished by the completion and return of the product registration form included in the SwapLoader hoist manual. If the owner is not sure that product registration is completed, then SwapLoader encourages them to contact us at 888-767-8000 to confirm.
- Defective parts must be reported to SwapLoader within 30 days of discovery on a SwapLoader warranty claim report form. A Return Goods Authorization (RGA) number must be issued to the claiming party prior to the return of any defective part to be considered for warranty.
- Warranty service must be performed by a distributor or service center authorized by SwapLoader to sell and/or service SwapLoader products, which will use only new or remanufactured parts or components furnished by SwapLoader U.S.A., Ltd. SwapLoader will invoice the distributor or authorized service center for the replacement parts and freight. Upon completion of the repair any defective parts to be returned for warranty consideration must be returned freight prepaid with a copy of the SwapLoader issued RGA form and a copy of the completed warranty claim report form. Upon evaluation of the returned parts, once warranty is approved, credit will be issued to the appropriate account for the approved warranty costs which may include parts, labor, and/or freight.
- The warranty covers only defective material and workmanship. It does not cover depreciation or damage caused by normal wear and tear, accident, mishap, untrained operators, or improper or unintended use. The owner has the obligation of performing routine care and maintenance duties as stated in SwapLoader's written instructions, recommendations, and specifications. Any damage resulting from owner/ operator failure to perform such duties shall void the coverage of this warranty. The cost of labor and supplies associated with routine maintenance will be paid by the owner.
- In no event will SwapLoader, the SwapLoader distributor or any company affiliated with SwapLoader be liable for business interruptions, costs of delay, or for any special, indirect, incidental or consequential costs or damages. Such costs may include, but are not limited to loss of time, loss of revenue, loss of use, wages, salaries, commissions, lodging, meals, towing, hydraulic fluid, travel, mileage, or any other incidental costs.
- SwapLoader is not responsible for the removal or replacement of accessories (fenders, toolbox, etc.).
- Warranty shall not apply if the equipment is operated at capacities in excess of factory recommendations.
- Warranty is expressly void if the seal on the main relief control valve has been broken.
- SwapLoader will ship the replacement part by the most economical, yet expedient means possible. Expedited freight delivery will be at the expense of the owner.
- Warranty is expressly void if serial number plate or stamping is tampered with.


IT IS EXPRESSLY UNDERSTOOD AND AGREED THAT THERE ARE NO WARRANTIES MADE BY THE MANUFACTURER OR ITS AGENTS, REPRESENTATIVES OR DISTRIBUTORS, EITHER EXPRESSED, IMPLIED, OR IMPLIED BY LAW, EXCEPT THOSE EXPRESSLY STATED ABOVE IN THIS STANDARD LIMITED WARRANTY AGAINST DEFECTS IN MATERIAL AND WORKMANSHIP. THE MANUFACTURER AND ITS AGENTS, REPRESENTATIVES AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

SWL Warranty 083109




SAFETY SUGGESTIONS



1. Do not operate or service this equipment until you have been properly trained and instructed in its use and have read the operation and service manual.



2. Do not operate this equipment on uneven ground.




3. Do not drive with the hoist in the dump position or with the hook to the rear.




4. Do not exceed 1,500 Engine RPM when operating the Power Take Off (P.T.O.). Never leave the P.T.O. in gear while transporting.
5. The hoist must be used with containers that properly fit the hook and rear holddowns. The container specifications must match the hoist specifications.
6. Keep the containers and hoist in good working order. **DO NOT** use if repairs are needed. Perform periodic inspections and maintenance as required by the maintenance section of the operator's manual.

7. Make sure work area is clear of people and obstacles prior to dumping or unloading containers. SwapLoader strongly recommends that a back up alarm be installed on the truck chassis. The operation of the hook hoist is that the truck is backed up to the body to pick it up and so there is a potential pinch point between the body and the hook.




8. Any container, which is on the hoist, **MUST** be unloaded prior to performing any repairs or maintenance to the hoist. Also, **DO NOT** allow any person to work on or be under the hoist in a raised position without first installing adequate safety blocks to eliminate all possibility of the hoist accidentally lowering. SwapLoader strongly recommends that if possible the container should be dismounted from the hoist prior to performing any maintenance to the hoist.



9. It is the responsibility of the owner and/or installer to insure that any additional safety devices required by state or local codes are installed on the SwapLoader Hoist and/or Truck Chassis.


10. Keep away from overhead power lines. Serious injury or death can result from contact with electrical lines. Use care when operating hoist near electrical lines to avoid contact.



11. Avoid contact with high-pressure fluids. Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid hazardous conditions by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard, while protecting hands and body from the high-pressure fluids.










12. It is the responsibility of the owner to provide proper maintenance of the Safety Decals. Regular inspection and replacing of Safety Decals that have any fading or damage which would impair their function should be done (See the illustration on the following page for location of Safety Decals).




ITEM	QTY	P/N	DESCRIPTION
1	2	90P07	OPERATION & SERVICE MANUAL
2	2	90P08	HOIST-BODY SPECIFICATIONS
3	ONE	90P09	HYDRAULIC OIL SPECIFICATIONS
4	ONE	90P10	HYDRAULIC OIL FLAMMABLE
5	2	90P11	HOIST FALLING
6	ONE	90P13	SAFETY INSTRUCTIONS
7	ONE	90P18	RELIEF VALVE
8	ONE	90P52	PROP DECAL
9	ONE	90P78	HIGH-PRESSURE FLUID

The following is a list of all the Swaploader Safety Decals, and their part numbers. Please use when reordering replacement decals.

90P07 – OPERATIONS & SERVICE MANUAL	
-------------------------------------	--

90P08 – HOIST-BODY SPECIFICATIONS	
90P09 – HYDRAULIC OIL SPECIFICATIONS	
90P10 – HYDRAULIC OIL FLAMMABLE	
90P11 – HOIST FALLING	
90P13 – SWAPLOADER SAFETY INSTRUCTIONS	
90P18 – RELIEF VALVE	

<p>90P52 – PROP DECAL (OPTIONAL)</p>	<div data-bbox="956 174 1300 369" data-label="Image"> <p>Hoist Prop Operation</p> <ol style="list-style-type: none"> 1. Unload Container From Hoist 2. Raise Hoist And Rotate Prop Into Upright Position. 3. Slowly Lower Hoist Until It Just Contacts Top Of Prop. Make Sure Prop Is Inserted Into Retaining Pocket On Hoist. 4. DO NOT POWER HOIST DOWN ONTO PROP! 5. See Operations Manual For Additional Information Regarding Operation. <p>90P52</p> </div>
<p>90P78 – HIGH-PRESSURE FLUID</p>	<div data-bbox="935 453 1321 590" data-label="Image"> <p> WARNING</p> <p>Avoid contact with high-pressure fluids. Escaping fluid under pressure can penetrate the skin causing serious injury. SEEK MEDICAL ATTENTION IMMEDIATELY!</p> <p>90P78</p> </div>

INSTALLATION

INITIAL INSPECTION

When the SwapLoader hoist is received from the factory, you should inspect the hoist for damage, which may have occurred in shipment. If damage has occurred, you should contact the shipper immediately. Be sure to note any damage or missing items on bill of Lading.

You should then check the hoist to insure you have received all the parts as indicated by the Packing List and the Ship Loose Box List.

If you have any problems, shortages, or questions, please contact SwapLoader U.S.A., Ltd. immediately.

GENERAL INSTALLATION PROCEDURE

The installation of the SwapLoader on a truck chassis will generally follow these steps:

1. Install hoist assembly onto truck chassis.
2. Mount the hydraulic control valve to the hoist and install the hydraulic plumbing from the control valve to the hydraulic cylinders. Then install the control levers in the cab and route the control cables to the hydraulic control valve assembly.
3. Install the hydraulic tank, hydraulic filter, and hydraulic plumbing between the hydraulic tank and the control valve assembly.
4. Select and install the P.T.O. on the truck transmission. (Note: This can be done prior to hoist installation on the truck chassis.)
5. Install the hydraulic pump and the plumbing from the pump to the hydraulic tank and control valve assembly.
6. Fill the hydraulic tank with oil, bleed the air from the pump suction line, and start up the unit.

Although SwapLoader attempts to include the mounts and attaching fasteners with each hoist unit, your particular installation may require some additional mounts or modifications. If you have problems with your installation, please contact SwapLoader at 1-888-767-8000, as we may be aware of another customer who has installed a SwapLoader on a similar truck chassis.

HOIST INSTALLATION TO TRUCK CHASSIS

1. Place the SL-145 hoist assembly on the truck chassis. The truck chassis mounting surface should be flat without any steps or protrusions. If necessary shim bars need to be added to ensure a flat surface on which to support hoist. The truck chassis should meet the following minimum specifications (See Figures A & B):

RBM for each frame channel: 500,000 in.-lb.

Total RBM: 1,000,000 in.-lb.

Minimum clear frame rail for mounting: 152" (See Fig. A)

Front Axle Cap: 6,000 lb. (Min)

Total Rear Axle Capacity: 12,000 lb. (Min)

CA Dim: 102" to 120" (120" preferred)




Figure A

Note: The above specifications are a minimum requirement. It is the responsibility of the owner/operator to ensure the completed chassis meets or exceeds all federal, state, and local regulations. Also, the hoist should not be used to lift and haul any load that exceeds the load rating of any of the individual components of the completed chassis (tires, axles, suspension, etc.)

The clear frame dimension indicated in the picture above allows for the overall length of the hoist plus 5 inches for cab clearance and rear light bar mounting. Extra frame length may be needed to allow for mounting additional accessories (e.g. Cab Guard, Tarper, Light Kit, etc.). For example, when mounting a light kit on a truck with a long CA, check that the hoist and the light kit are positioned far enough back to eliminate any interference between the fender and the light kit. You should also consider the final weight distribution with regard to the bridge code when positioning the hoist.

2. There are two types of mount brackets used on the Model SL-145 hoist as indicated in Figure B or Drawing No. 12H42. They are the front mount brackets (Pt. No. 22H38), and the rear mount brackets (Pt. No. 22H39).




Figure B

Locate the mount brackets on the side of the hoist as indicated in Figure C. These dimensions are flexible because of possible interference with chassis components. Also allow for mounting the control valve assembly and the hydraulic tank. You should consult the truck chassis supplier for any limitations regarding drilling mount holes in the truck chassis frame rails. Typically, the holes must be at least 2 $\frac{3}{4}$ " from the top of the truck chassis rails (Reference figure C & D).

Once the locations of the mount brackets have been determined, use the mount brackets as a template for marking the mounting holes in the truck chassis frame rails. Drill the $\frac{17}{32}$ diameter holes required and attach the brackets to the truck chassis with the $\frac{1}{2}$ -inch diameter bolts, washers, and locking hex nuts provided. Torque to 110 ft.lbs.

3. Weld the mount brackets to the hoist mainframe as indicated on Figures C thru D. You may need to modify the mount brackets or add shim plates to allow for variances in the width of the truck chassis as well as to allow for top rivets, stepped channels, etc.




Figure C






Figure D

Note: Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be connected as close as possible to the part being welded to avoid the possibility of arcing across bearings, gears, etc.


Note: The hoist mainframe is made from high strength low alloy steel. Use an appropriate welding process.



PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	11H81	DECAL ASSEMBLY	-	NOT SHOWN
2	ONE	11H82	PARTS & OPERATIONS MANUAL	-	NOT SHOWN
3	8	22H38	FRONT BRACKET	1.72	
4	2	22H39	REAR BRACKET	2.10	
5	3	00752	5/16 ϕ LOCK WASHER	0.04	
6	4	00755	3/8 ϕ LOCK WASHER	0.05	
7	26	00784	1/2 ϕ FLAT WASHER H.T.	0.02	F-436
8	26	00P15	1/2-13 x 1 3/4 HHCS	0.15	GR-8
9	4	00P13	3/8-16 x 1 1/4 HHCS	0.13	GR-8
10	4	00P14	3/8-16 HEX NUT	0.10	GR-8
11	3	00P19	5/16-18 x 2 3/4 HHCS	0.13	GR-8
12	3	00P20	5/16-18 HEX NUT	0.09	GR-8
13	26	00P35	1/2-13 LOCKING HEX NUT	0.06	GR-C
14	2	10P28	HEX BOLT 5/16 ϕ x 1 1/4	0.03	HEX-T2
15	2	10P29	COVER PLATE	0.10	TCP-T2
16	2	10P30	CLAMP HALF ASSEMBLY	0.04	T2050
				26.18	TOTAL



SECTION A-A



SECTION B-B





HOIST INSTALLATION KIT ASSY

SL-145
12H42

CONTROLS INSTALLATION - MANUAL

1. Attach the valve mount bracket (Pt. No. 10H51) to the mainframe as indicated on Dwg. No. 90H72 with the fasteners provided.
2. Mount the hydraulic control valve assembly (Pt. No. 21P32) to the valve mount bracket as shown on Drawing No. 90H72 with the fasteners provided.
3. Install the hydraulic adapters, connect the hydraulic tubing (Pt. Nos. 10P53, and 10P54), and connect the hydraulic hose assemblies (Pt. No. 12P59) to the control valve assembly as indicated on Drawing No. 90H90. The tubing should be supported by the clamp assemblies that are provided in the Loose Parts Box (See Drawing 12H42).
4. Determine the best location in the cab for the control levers (Pt. No. 20P08). The location should be such that the controls can be easily reached while operating the truck. A control lever console (Pt. No. 20P09) is provided to facilitate the mounting of the control levers.
5. Assemble and install the control lever console (See diagram below). Typically the console is fastened to the floor of the cab and the control cables are routed through additional holes drilled in the floor. Your particular installation may require that additional brackets be fabricated or other modifications made.





PARTS LIST					
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	10H51	VALVE MOUNT BRACKET WDMT	8.24	
2	ONE	21P32	HYD VALVE ASS'Y	27.00	
3	2	20P08	REMOTE VALVE CONTROL HANDLE	2.80	
4	ONE	20P09	CONTROL HANDLE MOUNT CONSOLE	4.05	
5	2	20P10	BONNET CONNECTION KIT	0.50	
6	2	20P15	CONTROL CABLE 84" LG	1.75	
				49.39	TOTAL

NOTE:
A 2 SECTION CONTROL VALVE ASS'Y IS SHOWN. A 3 SECTION CONTROL VALVE ASS'Y IS REQUIRED WHEN A STABILIZER IS UTILIZED



MANUAL CONTROL ASS'Y - 2 SECTION

SL-105/145/180

90H72 ~ REV A



NOTE:
HYD TANK ASS'Y CONSISTS OF:
TANK WELDMNT, TANK MOUNTED STRAINER,
SIGHT GAUGE, FILLER/BREATHING CAP,
MAGNETIC DRAIN PLUG, AND PORT PLUGS.



SWAPLOADER™
U.S.A. LTD.

HYD. SUB-ASS'Y - CHASSIS TANK CIRCUIT

SL-145


90H90

6. Attach the control cables to the control levers and route the cable through the holes in the cab. Install the control levers in the console. Levers should be installed such that when the levers are pushed forward the control cable is extended. See Drawing No. 90H72 (Manual Control Assembly) for control lever orientation.
7. Route the cables to the control valve location and attach them to the control valve with the bonnet connection kits provided (Pt. No. 20P10). See the following instruction sheet for installation procedures. The control cables supplied are 84 inches long. Your particular mounting may require different length control cables, which can be purchased locally or through Swaploader. Take proper care when routing the control cables, as a good cable path is essential for a proper operating system. Keep bends in the cable path to a minimum and be as generous as possible. Under no circumstances should any bend be tighter than an 8" radius. Protect the cable from heat above 225 degrees F. and avoid hot areas such as exhaust pipes, etc.. Protect the cable from physical damages such as pinching or crushing, and do not use cable supports, which may crush or deform the cable. Allow room for flexing where the cable is attached to moving parts of the equipment, so that the cable is neither kinked nor stretched.

INSTALLATION PROCEDURE FOR A HYDRAULIC CONTROL CABLE TO HYDRAULIC VALVE WITH BONNET CONNECTION KIT



1. Turn .750-16 UNF Jam Nut entire length of Threaded Hub back over the Cable. Place Flange onto Sleeve.
2. Turn Flange/Sleeve Assembly entire length of Threaded Hub back over the Cable.
3. Turn .250-28 UNF Jam Nut onto Threaded Rod until it bottoms.
4. Turn Terminal Eye onto Treaded Rod until it bottoms against Jam Nut. (Minor adjustments may be necessary to align Terminal Eye with spool yoke.)
5. Slide the Terminal Eye into yoke on spool and align the holes. Insert Clevis Pin through yoke and Terminal Eye holes. Install Retaining Ring into groove between Terminal Eye and one side of the Yoke.
6. Now, with the Cable attached to the valve and control head, turn the Flange/Sleeve Assemble back onto the Threaded Hub until it is flush with the valve face. When turning on the Flange/Sleeve Assembly, make sure that the control head remains in neutral.
7. Thread the .750-16 UNF Jam Nut back over Threaded Hub and tighten against the Sleeve to lock in position.
8. Bring Flange into position on bolt assembly to valve housing.

NOTE: FOR WORK SECTION NEXT TO INLET COVER, USE SPACER KIT.



HYDRAULIC TANK INSTALLATION

1. Select a location to mount the hydraulic tank. Reference Figure E or Drawing No. 90H72 for the suggested location of the hydraulic tank to the rear of the control valve assembly on the left-hand side of the truck. The hydraulic hoses have been sized for the tank to be mounted in this general area. The tank can be located on the right-hand side or behind the cab, if necessary, which means longer hoses may be required.
2. Drill four (4) holes for 1/2-inch diameter bolts (provided) in the mount angle of the hydraulic tank (two per angle) and the frame rails of the truck chassis. Mount the hydraulic tank and install the hydraulic filter. Install the hydraulic return hose and the hose barb fitting between the filter and the control valve assembly as shown on Drawing No. 90H90. The hose length can be shortened if necessary. Secure the hose to the barb fittings with the hose clamps provided.



SECTION A-A

Figure E

P.T.O. SELECTION

The next step is to select and install a direct drive type P.T.O. to the transmission. Please contact your local truck equipment representative for the correct unit sized on the following criteria:

P.T.O. Torque Rating:	125 ft.-lbs. (See Note 1)
Power at 1500 RPM:	36 H.P. (See Note 1)
Output Flange:	SAE B 4 Bolt
Hydraulic Pump Spined Shaft Specifications:	7/8 – 13T 16/32 D.P.
Hydraulic Pump Rotation:	L.H. As provided (See Note 2). The hydraulic pump rotation can be reversed to R.H. by a qualified hydraulic technician or it can be sourced through Swaploader.
Ratio of Pump RPM to Engine RPM:	80% to 100%

NOTE 1: P.T.O. torque and power requirements are based on the unit operating at main relief pressure. Normal operating pressure will be less.

NOTE 2: P.T.O. output rotation will need to be R.H. (clockwise) as viewed looking at output flange of P.T.O. for a L.H. Pump.

NOTE 3: Do not operate pump at speeds over 1500 R.P.M.

NOTE 4: Always disengage the P.T.O. after each operating cycle.

HOW TO IDENTIFY WHAT PUMP IS NEEDED

The SwapLoader factory supplied pump is a bushing style gear pump, because of the pressure requirements of the SwapLoader hooklift hoist. By design the bushing style pumps are single rotation (rotation specific).


All SwapLoader hooklift hoists come standard with a CCW (left hand rotation pump), which will work for most manual transmission applications. For most automatic transmission applications a CW (right hand rotation pump) is needed; call SwapLoader for price and availability. **NOTE: Consult the PTO supplier whenever uncertain about the correct pump rotation for a particular application.**

The table below lists the SwapLoader part number for both left and right hand rotation pumps for the SL-145 hoist model:

MODEL	L.H. Rotation Pump (standard)	R.H. Rotation Pump (special)
SL-145	20P53	20P98

HOW TO IDENTIFY PUMP ROTATION

To better understand the effects of pump rotation we must consider the path that oil takes through the pump. Oil enters the pump through the inlet (suction) port, travels around the outside of the gears, and is forced out through the outlet (exhaust) port. Oil enters and exits the pump in the direction of its rotation.






Determine pump rotation by positioning the pump belly side down (see illustration above). Looking at the rear of the pump if the suction (largest) port is to the left side, then the pump is a CCW or left hand rotation. If the suction (largest) port is on the right side, then the pump is CW or right hand rotation.

PUMP INSTALLATION


1. Install the hydraulic pump to the P.T.O. (Bolts are not provided).
2. Install the hydraulic fittings into ports on the hydraulic pump as shown on Drawing No. 90H91.
3. Connect the suction hose assembly to the hydraulic tank (1" I.D. hose) and route to the hydraulic pump in as short and straight line as possible. Be sure to route the hose clear of exhaust components and of the drive shaft. Extra hose is provided so the hose can be shortened to an appropriate length. Install the hose on the hose barb fittings at the tank and at the pump and secure with the hose clamps provided.

NOTE: Prior to startup, this hose must be filled with oil.

4. Connect pressure hose assembly (1/2 inch I.D. hose) to control valve inlet and route to the pump the same as the suction line. This hose is provided with only one fitting, so the hose can be shortened to appropriate length. Remove the hose and shorten as required. After the hose has been shortened, lubricate the insert threads of the fitting and the I.D. of the hose. Measure 1 3/16 inches from the end of the hose and mark the hose for the socket depth. Screw hose into the socket (left-hand thread) to the depth marked on the hose. Screw insert in socket until insert touches the socket. Clean the inside of the hose assembly by either blowing clean compressed air through it or by flushing it. Install the completed hose assembly to the inlet port of the control valve assembly and the outlet port of the hydraulic pump.




5. Tie up the pressure and suction hoses as necessary. Again, be sure the hoses are routed to avoid exhaust components and to stay clear of the drive shaft.



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	10P21	1 1/2Ø T-BOLT CLAMP	0.10	TBC-150
2	ONE	10P32	ADP, HYD MJIC / ORB 45°	0.30	6802-10-12
3	ONE	10P35	ADP, HYD MJIC / ORB	0.30	6400-10-12
4	ONE	10P61	HOSE ASS'Y 1/2 HP x 106	4.42	
5	ONE	12P18	ADP, HYD HOSE INS / ORB	0.40	4604-16
6	ONE	12P19	ADP, HYD HOSE INS / MP	0.30	ST10
7	ONE	12P20	ADP, HYD MP / FP	0.30	1 1/4 x 1
8	ONE	12P28	HOSE 1 LP x 120	6.60	
				12.82	TOTAL




U.S.A. LTD.

HYD. SUB-ASS'Y - PUMP CIRCUIT
SL-105/145/180
90H91

START UP PROCEDURE

1. Fill the hydraulic tank with hydraulic oil (see oil specification in Maintenance Section.)
2. Prime the pump by loosening the clamp on the suction hose at the pump. Pull the hose back off the fitting till the air is bled from the line. Push the hose back on the fitting and retighten the clamp.
3. Engage the P.T.O. and run the pump at idle (700 to 900 RPM). Operate the cylinders at full stroke five to ten times to bleed the air from the lines and cylinders. The cylinders were filled with oil during testing at the factory, but some seepage may have occurred during shipping and installation. Refill the hydraulic tank, if needed, during this sequence and do not let the pump run without oil.
4. Check for leaks and tighten fittings as necessary.
5. Verify the movement of the control levers corresponds to the movement of the cylinders per the figure below.



6. Install all safety decals and product decals per Drawing No. 11H81 after final installation and painting have been completed. The factory prior to shipment of a hoist, will install some decals that have a premask layer. The premask will need to be removed after painting the hoist. It is very important when removing the premask not to pull the premask out and away from the decal at a 90° angle, but instead pull the premask straight down at a 180° angle to the decal surface. Should problems occur with the premask pulling the decal loose, wet the tack side of the premask with water via a spray bottle to weaken the adhesive bond, while pulling straight down on the premask.

7. Fill out pre-delivery checklist and warranty card and mail to SwapLoader U.S.A., Ltd.

NOTE: Failure to fill out and return warranty card within 15 days of installation may possibly void the warranty.



CAUTION: The SwapLoader hoist must be used with bodies or containers that properly fit the front hook and the rear hold-downs (See figure S025). If possible, pick up one of the containers that will actually be used with the SwapLoader hoist and verify the following:

- Outside dimensions of the long sills match the guiding rollers on the hoist.
 - The front hook dimensions are correct for the hoist.
 - The rear hold-downs of the container latch into the hold-downs on the hoist.
 - Check for any interference between the container and any part of the hoist (i.e.: Hydraulic tank, hydraulic tubing or hose, hydraulic valve, etc.)
-




An EFCO Company


SWAPLOADER®


"Hooked on Quality" U.S.A. LTD.

100 SERIES SUB-FRAME CRITICAL DIMENSIONS



100 SERIES SUB-FRAME DIMENSIONS	
HOIST COMPATABILITY	A
SL-95/105	82 1/2" [2096 mm]
SL-125/145/180/185	95 1/2" [2418 mm]


 U.S.A. LTD.		
TITLE		
100 SERIES SUB-FRAMES		
DRAWING NO.	MODEL NO.	REV
S-933		A



An EFCO Company

SWAPLOADER[®]


U.S.A. LTD.



REAR BUMPER ASSEMBLY (52H11)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation.
2. Trim truck frame to indicated dimensions (See Fig. 1). These dimensions will facilitate the mounting of the rear light assembly if it is also being mounted.
3. Measure the distance from the bottom of the truck frame to the ground (NOTE: This should be performed on a level surface). Based this measurement and the dimensions in Fig. 1, the vertical channel [P/N: 63H94] may need to be modified in length to meet the Office of Motor Carrier Safety (OMCS) regulations. Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Fig. 2). Once the length has been determined for the vertical channels, weld them to the truck frame (See additional notes on next page).
4. Center the bumper weldment [P/N: 52H12] on the vertical channels [P/N: 63H94]. Position rear of bumper from rear of the hoist as indicated by the bumper location chart. This is crucial in order to ensure that the container longills do not contact the bumper during the dump cycle (See Fig. 1 & 2).



BUMPER LOCATION CHART								
DIM. A	DIM B. (Max)							
	SL-105	SL-145	SL-180	SL-220/222 & SL-240	SL-2418	SL-330 & SL-400	SL-406 & SL-505/545	SL-650
24 5/8"	13 1/2	15 3/4	15 1/4	17	14 1/4	14	16 1/2	18
22 5/8"	12 1/4	14 1/2	14	15 3/4	13	12 3/4	15	
20 5/8"	11	13	12 3/4	14 1/4	11 3/4			
18 5/8"	9 3/4	11 3/4	11 1/2					

All Figures are for Illustration Purposes Only


10/05/09

REAR BUMPER ASSEMBLY

(52H11)

INSTALLATION INSTRUCTIONS (continued)

5. Weld the bumper weldment to the vertical channels (See Fig. 1 & 3).





ADDITIONAL NOTES:

1. *Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.*
2. *All welds should be done utilizing a low hydrogen welding process.*

MATERIAL LIST

ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	1	52H12	REAR BUMPER WDMT	95.66
2	2	63H94	VERTICAL CHANNEL	9.58
TOTAL				114.82






REAR BUMPER ASS'Y w/ EXTENSIONS

(52H11 with 52H13 Extensions)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation.
2. Trim truck frame to indicated dimensions (See Fig. 1). These dimensions will facilitate the mounting of the rear light assembly if it is also being mounted.
3. Measure the distance from the bottom of the truck frame to the ground (NOTE: This should be performed on a level surface). Based this measurement and the dimensions in Fig. 1, the vertical channel [P/N: 63H94] may need to be modified in length to meet the Office of Motor Carrier Safety (OMCS) regulations. Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Fig. 2). Once the length has been determined for the vertical channels, weld them to the truck frame (See additional notes on next page).
4. Center the bumper weldment [P/N: 52H12] with factory installed extensions [P/N: 52H13] on the vertical channels [P/N: 63H94]. Position rear of bumper from rear of the hoist as indicated by the bumper location chart. This is crucial in order to ensure that the container longills do not contact the bumper during the dump cycle (See Fig. 1 & 2).



BUMPER LOCATION CHART								
DIM. A	DIM B. (Max)							
	SL-105	SL-145	SL-180	SL-220/222 & SL-240	SL-2418	SL-330 & SL-400	SL-406 & SL-505/545	SL-650
24 5/8"	19 3/4	22 1/2	21 3/4	25 1/4	21 3/4	21 1/2 *	24 1/4 *	27
22 5/8"	18 1/2	21	20 1/2	23 3/4	20 1/2	20 *	22 3/4 *	
20 5/8"	17 1/4	19 1/2	19 1/4	22 1/4	19 1/4			
18 5/8"	16	18 1/4	18					

* Dimensions assume 6" tall longills. For 8" tall longills add 2 1/4" to the dimension shown.

All Figures are for Illustration Purposes Only


05OCT09

REAR BUMPER ASS'Y w/ EXTENSIONS

(52H11 with 52H13 Extensions)

INSTALLATION INSTRUCTIONS (continued)

5. Weld the bumper weldment to the vertical channels (See Fig. 1 & 3).




ADDITIONAL NOTES:

1. Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. All welds should be done utilizing a low hydrogen welding process.

MATERIAL LIST


ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	1	52H12	REAR BUMPER WDMT	95.66
2	2	63H94	VERTICAL CHANNEL	9.58
3	1	52H13	REAR BUMPER EXTENSIONS	58.42
TOTAL				173.24





SWAPLOADER[®]


U.S.A. LTD.



CAB GUARD ASSEMBLY (50H99)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting cab guard installation.
2. Position cab guard weldment [Part No. 50H95] on frame with sufficient clearance between cab and cab guard (See Fig. 1).
3. Determine location for mounting holes. Mounting holes should not be located within 2-3/8" of the truck frame edge (See Fig. 1). Drill 21/32" dia. mount holes through cab guard channels.




CAB GUARD ASSEMBLY (50H99)

INSTALLATION INSTRUCTIONS (continued)

4. Mark mounting holes through the cab guard weldment onto truck frame. Remove cab guard weldment and drill $2\frac{1}{32}$ " dia. holes in truck frame.
5. Attach cab guard weldment to truck frame using fasteners provided (See Fig. 2).

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	1	50H95	CAB GUARD WDMT.	295.36
2	4	00P69	5/8-11 X 2 HHCS	.33
3	4	00P55	5/8-11 LOCKING HEX NUT	.18
4	4	00785	5/8 DIA. WASHER HT.	.08
TOTAL				292.72



CONTAINER VARIABILITY SYSTEM ASSEMBLY

(11H99)

[Hoist Models: SL-145 & SL-180]

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting the C.V.S. installation.
2. Attach the base plate bracket [Part No. 23H76] to the C.V.S. sub-assembly [Part No. 12H01] with fasteners provided (See drawing 11H99 *Section View A-A*).
3. Position the C.V.S. sub-assembly with attached base plate bracket on the side of the mainframe z-channel (See drawing 11H99). Drill the necessary 13/32 Dia. holes into the z-channel using the C.V.S. sub-assembly with attached base plate bracket as the pattern to aid in locating hole placement. To allow for C.V.S. sub-assembly [Part No. 12H01] fastener clearance some notching of the z-channel lip may be necessary.
4. Attach the C.V.S. sub-assembly and base plate bracket to the mainframe z-channel with fasteners provided (See drawing 11H99).
5. Drain hydraulic oil level in the tank to just below the 1 1/4" NPT Port.
6. Remove the 90 degree hydraulic fitting [Part No. 10P44] that connects the upper hydraulic steel tubing to the top bulkhead fitting (See drawing 90H90). Replace with a swivel tee hydraulic fitting [Part No. 11P85] and retighten the hydraulic fittings (See drawing 90H84).
7. Remove the 1 1/4" NPT plug from the hydraulic tank. Install hydraulic fittings 12P20 & 12P92 as shown and tighten (See drawing 90H84).
8. Install the two 90 degree hydraulic fitting [Part No. 12P69] into the hydraulic valve on the 12H01 C.V.S. sub-assembly and tighten (See drawing 90H84).
9. Attach the hydraulic hose [Part No. 12P87] between the C.V.S. hydraulic valve and swivel tee hydraulic fitting [Part No. 11P85], and tighten (See drawing 90H84).
10. Determine the length of hose required to route the C.V.S. hydraulic valve to the hydraulic tank; the hydraulic hose [Part No. 12P93] may need shortened prior to final installation (See drawing 90H84) especially if excess length exists. The hydraulic hose [Part No. 12P93] comes with a reusable fitting that can be removed for purposes of shortening the hose. Remove the reusable fitting and shorten hose assembly as required. After hose has been shortened, lubricate the insert threads of the fitting and the I.D. of the hose (See Fig. 1). Measure 1 3/16 inches from the end of the hose and mark the hose for the socket depth. Screw the hose into the socket (left-hand thread) to the depth marked on the hose. Screw the insert into the socket until the insert touches the socket. Clean the inside of the hose assembly by either clean compressed air through it or by flushing it.





Figure 1


11. Once the overall hose length is adjusted, install between the C.V.S. hydraulic valve and the hydraulic tank fittings (See drawing 90H84), and tighten.
12. Remove both the hydraulic hose [Part No. 12P55] that connects from the upper bulkhead fitting inside the mainframe to the jib lockout valve [Part No. 21P28] and the 90 degree hydraulic fitting [Part No. 11P23] installed into the top side of the jib lockout valve (See drawing 90H73).
13. Replace with hydraulic fittings [Part No. 12P69 (Qty: 2) & 13P03], hydraulic hose [Part No. 11P98], and relief valve assembly [Part No. 21P93] and tighten (See drawing 90h84).
14. Refill hydraulic tank to proper fluid level.
15. Verify that the C.V.S. is operating properly. Start the truck, engage the P.T.O., and then retract the jib cylinder full stroke. Next, while extending the jib cylinder back out have someone push or rotate the C.V.S. lever arm forward (toward the back of the truck cab). The C.V.S. is operating properly when the jib cylinder stops extending by rotating the C.V.S. lever arm forward.
16. Containers to be used in conjunction with the C.V.S. need modified by adding a stop tab to the side of the container long sill (See drawing S-878). Dimensions given are a recommendation only. When modifying containers for use with the C.V.S. it is the primary responsibility of the installer to verify that adequate rear end overhang and full latch plate engagement into body locks exists for each container.





MATERIAL LIST					
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS
1	ONE	12H01	C.V.S. SUB-ASS'Y	11.23	
2	ONE	23H76	BASE PLATE BRACKET	5.27	
3	6	00755	3/8" LOCK WASHER	0.01	
4	6	00P13	3/8-16 x 1 1/4 HHCS	0.06	GR 8
5	6	00P14	3/8-16 HEX NUT	0.02	GR 8
6	ONE	90H84	C.V.S. HYD CIRCUIT ASS'Y	8.36	
7					
8					
9					
10					
11					
12					
				25.40	TOTAL


NOTE:

1. DRILL 13/32" HOLES INTO THE MAINFRAME AS NEEDED TO POSITION THE 12H01 AS INDICATED. USE THE 12H01 & 23H76 AS A PATTERN TO AID IN LOCATING HOLE PLACEMENT.
2. SEE DRAWING S-878 FOR THE RECOMMENDED CONTAINER LONGSILL STOP TAB LOCATION.


A		REVISED SL-180 DIM'S		7/28/09	DGS
NO.		REVISION		DATE	BY
GENERAL NOTES					
1. ANY ALTERATION OR REPAIR OF SWAPLOADER EQUIPMENT MUST BE AUTHORIZED IN WRITING BY SWAPLOADER USA, LTD. AND MUST BE CARRIED OUT BY QUALIFIED PERSONNEL. ANY MODIFICATION OF EQUIPMENT OR USE OF THAT EQUIPMENT OTHER THAN AS SHOWN WILL VOID ALL WARRANTIES.					
2. THIS DRAWING IS THE PROPERTY OF SWAPLOADER USA, LTD. AND IS LOANED TO THE RECIPIENT IN CONFIDENCE.					
3. ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SHOWN.					
					
TITLE CONTAINER VARIABILITY SYSTEM ASSEMBLY					
CUSTOMER					
DETAILED BY		06/24/04		DGS	
CHECKED BY		06/28/04		DGS	
PRINT DISTRIBUTION					
SHOP FILE		SCALE 3/4" = 12"		DRAWING NO. 11H99	
TOTAL					












An EFCO Company

SWAPLOADER[®]

U.S.A. LTD.





FENDER ASSEMBLY, SINGLE AXLE

Aluminum (10H93) / Steel (11H13)

(*Diamond Plate Only*)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting fender installation.
2. Center fender above tire using block to maintain the proper height. Fender should be approximately 5" above tire to allow for suspension movement (See Fig. 1). A maximum width of 48" from center of the truck to the outside edge of the fender should be maintained (See Fig. 2).
3. Place fender bracket weldments [Part No. 10H74] on fender. Position the brackets to avoid any mounting obstacles on hoist and/or truck chassis.




All Figures are for Illustration Purposes Only

10/02/09



SWAPLOADER[®]

U.S.A. LTD.





FENDER ASSEMBLY, SINGLE AXLE

Steel (11H52)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting fender installation.
2. Center fender above tire using blocks to maintain the proper height. Fender height should be 3" to 4" above tire to allow for suspension movement (See Fig. 1). A maximum width of 45-1/2" from center of the truck to the outside edge of the fender should be maintained (See Fig. 2).
3. Place fender bracket weldments [Part No. 11H50] on fender. Position the brackets to avoid any mounting obstacle on hoist and/or truck chassis.



FENDER ASSEMBLY, SINGLE AXLE

Steel (11H52)

INSTALLATION INSTRUCTIONS (continued)

4. Mark mounting holes through the fender bracket weldment onto the fender.
Remove the bracket and drill 7/16" dia. holes in fender.
5. Attach fender bracket weldments to fender using fasteners provided.
6. Position fender mount weldment [Part No. 11H51] on hoist mainframe;
align with fender bracket weldment. Mark mounting holes through the
fender bracket weldment onto the fender mount weldment. Drill 7/16"
dia. holes in fender mount weldment.
7. Weld fender mount weldment to hoist mainframe.
8. Weld guide gussets [Part No. 22H15] inside Z-channel of hoist mainframe
(See Fig. 3), two guide gussets per fender mount weldment.

MATERIAL LIST

ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	4	11H50	FENDER BRACKET WDMT.	6.98
2	4	11H51	FENDER MOUNT WDMT.	2.41
3	8	22H15	GUIDE GUSSET	.36
4	4	22H81	RUBBER SPACER	.77
5	12	00P77	3/8-16 X 3 HHCS	.18
6	12	00P78	3/8 DIA. NYLON WASHER	-
7	28	00771	3/8 DIA. FLAT WASHER	.05
8	28	00P34	3/8-16 LOCKING HEX NUT	.10
9	16	00P62	3/8-16 X 1 HHCS	.12
10	2	11H48	FENDER, STEEL TREAD PLATE	30.26
TOTAL				111.52

9. Attach fender bracket weldment
[Part No. 10H50] to fender mount
weldment [Part No 11H51] using
fasteners provided (See Fig. 3).

ADDITIONAL NOTE:
Prior to any welding, consult the
truck manufacturer for any spe-
cial precautions that may need to
be taken. Typically the batteries
must be disconnected and the
ground lead from the welder
should be connected as close as
possible to the part being welded
to avoid the possibility of arcing
across bearings, gears, etc.




FIG. 3




SWAPLOADER®

1800 N. E. Broadway Avenue, Box D, Des Moines, Iowa, U.S.A. 50316-0386
Telephone: (515)266-3042

Fax (515)266-3042

U.S.A. LTD.



REAR LIGHT BAR ASSEMBLY



(51H68)

REAR LIGHT BAR ASSEMBLY

((51H68))

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting rear light bar installation.
2. Trim truck frame to indicated dimensions (See Fig. 1). This step may have already been preformed if a bumper was previously installed.
3. Position center plate [Part No. 63H08] on the rear of the main frame. Weld center plate to truck frame (See Fig. 2 & Additional Notes).
4. Position stub light bar weldment [Part No. 51H69] on truck frame. Stub light bar weldment should be as high and as far back as possible on the truck frame to avoid interference with the bumper and fenders. It may be necessary to modify the stub light bar weldment to avoid interference. Drill mounting holes as required and mount using fasteners provided (See Fig. 3).
5. Attach the tail light module to the stub light bar weldments with the fasteners provided (See Fig. 3).
6. Mount the identification light bar at top center of the center plate [Part No. 63H08] using the fasteners provided (See Fig. 3).
7. Mount license lamp right of the license plate (See Fig. 2) using the fasteners provided (See Fig. 3).



REAR LIGHT BAR ASSEMBLY

((51H68))

8. Mount junction box on the back left side of center plate (See Fig. 2), using the fasteners provided (See Fig. 3).
9. Route all wire harnesses into the junction box. Wire harnesses must enter the junction box through a compression fitting (Based on the size of the wire harness, choose a compression fitting with an appropriately sized grommet). Make wiring connections in junction box with wire harness from truck cab as indicated on wiring diagram (See Fig.4).

MATERIAL LIST

ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH
1	2	51H69	STUB LIGHT BAR WDMT.	7.87
2	ONE	63H08	CENTER PLATE	27.33
3	6	00P44	3/8-16 x 1 1/2 HHCS	0.07
4	6	00P34	3/8-16 LOCKING HEX NUT	0.02
5	6	00771	3/8 DIA FLAT WASHER	0.01
6	4	01P18	5/8-11 x 3 HHCS	0.35
7	8	00P81	#8-32 x 1 RND HD SCR	-
8	8	00P82	#8-32 HEX NUT	-
9	8	00P83	#8 LOCK WASHER	-
10	ONE	40P26	LIGHT KIT ASSEMBLY	23.00
11	REF	40P27	LEFT TAIL LIGHT MODULE WITH HARNESS	-
12	REF	40P28	RIGHT TAIL LIGHT MODULE WITH HARNESS	-
13	REF	40P29	SIDE MARKER LAMP	-
14	REF	40P30	STOP, TURN, & TAIL LAMP	-
15	REF	40P31	BACK-UP LAMP	-
16	REF	40P32	LICENSE LAMP ASSEMBLY (WITHOUT HARNESS)	-
17	REF	40P33	LICENSE LAMP	-
18	REF	40P34	LICENSE LAMP HARNESS	-
19	REF	40P35	IDENTIFICATION LIGHT BAR RAIL	-
20	REF	40P36	ID LIGHT BAR LAMP	-
21	REF	40P37	ID LIGHT BAR HARNESS	-
22	REF	40P38	JUNCTION BOX ASSEMBLY	-
TOTAL				68.07

ADDITIONAL NOTES:

Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.




FIG. 3



1800 NE Broadway Avenue, Des Moines, Iowa, U.S.A. 50313-2644
 Phone: (515) 266-3042 • Fax: (515) 313-4426 • Toll Free: (888) 767-8000
 E-Mail: sales@swaploader.net • Web Site: www.swaploader.com

WIRE DIAGRAM






Fig. 4



SWAPLOADER[®]


U.S.A. LTD.



ROLLER & ROLLER MOUNT (10H90 & 10H91)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting the roller and roller mount installation.
2. Locate position for roller mount brackets [Part No. 32H03] between cross sills of the container. Rollers should be positioned as far back and as wide as possible for stability. For hoist and folding bumper clearance, do not place brackets any closer than 11" to the subframe longsill (See Fig.1). Also, the roller axle center line should be approximately 1-11/16" below the bottom of the subframe longsill for roller clearance (See Fig. 1).



ROLLER & ROLLER MOUNT (10H90 & 10H91)

INSTALLATION INSTRUCTIONS (continued)

3. Some modification to the roller mount bracket may be required for the roller mount to fit properly. If the existing container cross members are wider than 6", a fabricated support member of 1/2" plate or thicker will need to be added (See Fig. 2).
4. Once the mount brackets are located on the container, weld the roller mount brackets in place (See Fig. 1).
5. Install the roller [Part No. 10H12] between the brackets with the roller axle [Part No. 10H31] and the fasteners provided (See Fig. 3). Grease the rollers before use.




FIG. 2

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	4	32H03	ROLLER EAR	11.95
2	2	10H12	ROLLER WDMT.	39.78
3	2	10H31	ROLLER AXLE WDMT.	7.28
4	2	00P62	3/8-16 UNC X 1 BOLT	.05
5	2	90P03	1/8 NPT GREASE ZERK	.01
6	2	00755	3/8 DIA. LOCK WASHER	.01
7	2	00P36	3/8 DIA. WASHER H.T.	.10
TOTAL				142.26






FIG. 3



SWAPLOADER[®]

U.S.A. LTD.



TOOLBOX

Aluminum (10H92) / Steel (11H12)


INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting toolbox installation.
2. Position toolbox brackets [Part No. 10H88] on truck chassis.
(NOTE: toolbox has an envelope of 18"x18"x36". See Fig. 1 for hole dimensions.)
3. Mark position of mounting holes through brackets onto truck chassis. Remove brackets and drill 9/16" dia. holes.
4. Mount toolbox brackets using fasteners provided (See Fig. 1).
5. Position toolbox [Part No. 90P27 or 90P37] on brackets. (NOTE: toolbox hinge should be on the forward, bottom edge.)
6. Mark position of mounting holes through brackets onto toolbox. Remove toolbox and drill 9/16" dia. holes.
7. Mount toolbox to brackets using fasteners provided (See Fig. 1).

TOOLBOX

Aluminum (10H92) / Steel (11H12)

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	2	10H88	18" TOOLBOX BRACKET	11.34
2	2	22H71	TOOLBOX RUBBER SPACER (ALUMINUM TOOLBOX ONLY)	.27
3	1		18 X 18 X 36 TOOLBOX	
		90P27	ALUMINUM TOOLBOX	50.00
		90P37	STEEL TOOLBOX	72.00
4	8	00784	1/2 DIA. FLAT WASHER H.T.	.07
5	4	00P15	1/2-13 UNC X 1-3/4 HEX HEAD BOLT	.23
6	8	00P35	1/2-13 UNC METAL LOCKING NUT	.15
7	4	00P75	1/2-13 UNC X 1-1/2 SOCKET BUTTON HEAD BOLT	.12
8	4	00P76	1/2 DIA. NYLON FLAT WASHER (ALUMINUM TOOLBOX ONLY)	-
ALUMINUM TOOLBOX TOTAL				76.38
STEEL TOOLBOX TOTAL				97.84





PRE-DELIVERY CHECK LIST

INSPECTOR'S INFORMATION


Inspected By: _____ Signature: _____
Distributor: _____ Date Installed: _____
Customer: _____ Date Inspected: _____

I. COMPONENT INFORMATION


Hoist Model: _____
Hoist Serial No.: _____
Chassis VIN: _____
Chassis Make & Model: _____
Chassis GVWR: _____
Chassis CA / CT: _____
After Frame: _____

Distance from rear of cab to the centerline of rear axle/tandem.

Distance from centerline of rear axle/tandem to rear of hoist.



CA



CT

PTO Make: _____
PTO Model: _____
PTO Serial No.: _____
PTO % of Engine RPM: _____

Hyd. Pump Make: _____
Hyd. Pump Model: _____
Hyd. Pump Serial No.: _____

II. INSTALLATION TO CHASSIS

Were there any problems installing the hoist to the truck chassis? ☐ YES ☐ NO

If yes, please describe: _____

- ☐ All bolts checked for proper tightness.
- ☐ Please include photos of the hoist installed on the truck chassis. Be sure to include at least one photo from each side of the chassis/hoist.



III. CONTROLS

- ☐ Controls easy to operate from driver's seat.
- ☐ Movement of controls correct, per installation instructions.

IV. HYDRAULIC INSTALLATION

- ☐ Correct hydraulic oil level in reservoir, per installation instructions.
- ☐ Inspected for leaks.

Any abnormal noise during hoist operation? ☐ YES ☐ NO

If yes, please describe: _____

With engine operating @ 1,000 RPM, record the following information:

Cycle time for dump mode: _____	Seconds Up _____	Seconds Down _____
Cycle time for load/unload mode: _____	Seconds to Unload _____	Seconds to Load _____
Filter pressure: _____	PSI _____	
Main pressure, controls in neutral: _____	PSI _____	
Main relief pressure when extending jib cylinder (bottomed out): _____	PSI _____	
Main relief pressure when extending lift cylinders (bottomed out): _____	PSI _____	

NOTE: Connect pressure gauge to fitting provided on the inlet section of the Hydraulic Control Valve (Ref. Part No. 10P37, fitting on Hydraulic Pump Circuit Drawing found in the Parts List section of the Hoist's Parts & Operations Manual).

V. OPERATION

- ☐ Jib operates freely in both directions.
- ☐ Jib cannot be extended or retracted when raised in dump position or when pivot joint is tilted in unload position. Both safety hooks are fully engaged when jib is extended.
- ☐ Parts & Operations Manual is in the cab.
- ☐ Lubricate sliding jib and all grease zerks per installation instructions.

VI. DECALS

- ☐ All safety decals and product decals installed per enclosed decal drawings (found attached to the inside of the hoist's Parts & Operations Manual cover or at the back of the Parts List section in the Manual).

Additional Comments: _____

COMPLETE & SAVE TO YOUR COMPUTER. RETAIN A COPY FOR YOUR FILES.
ONCE COMPLETE, FAX (515-313-4426) OR EMAIL (sales@swaploader.net) A COPY BACK TO SWAPLOADER!

1800 NE Broadway Ave., Des Moines, IA 50313 • www.swaploader.com • Toll Free: 888-767-8000


OPERATION

OPERATING INSTRUCTIONS


During all operations of the SwapLoader, the speed of the engine should be maintained at 1,000 to 1,200 RPM, assuming the ratio of the Power Take Off is about 100%.

LOADING A CONTAINER


1. Engage the P.T.O. (Refer to P.T.O. manual for operation).



2. Retract the jib (right control lever backward). Then, tilt the arm backward (left control lever backward).




3. Make sure the work area in front of the container is clear of people and obstacles. Move the truck backwards until the hook engages the curved lifting bar of the container. **NEVER EXTEND THE JIB** to reach the proper catching height, rather tilt the arm.






WARNING:


Make sure work area is clear of people and obstacles prior to dumping or unloading containers. SwapLoader strongly recommends that a back up alarm be installed on the truck chassis. The operation of the hook hoist is that the truck is backed up to the body to pick it up and so there is a potential pinch point between the body and the hook.



4. Cycle the arm forward (left control lever forward), making sure the curved lifting bar is securely attached to the hook. Release the brakes of the truck and steer to correctly align the truck with the container. Watch the container rails to see that they come to rest centered on the rear rollers. Do not extend the jib during lifting.



5. When the container is resting on the frame, move the jib forward all the way to ensure the container is held in the body locks (right control lever forward).



DUMPING

1. Move the jib forward (right control forward) to ensure that the container is locked.
2. Extend the main lift cylinders (left control backward).




CAUTION:


DO NOT RETRACT THE JIB WHILE DUMPING. Retracting the jib during dumping may unlock the mechanical jib latches which could allow the container to crash down onto the hoist and/or abruptly unload.

PLACING A CONTAINER ON THE GROUND


1. Move the sliding jib all the way back (right control backward) until mechanical jib latches unlock.



2. Tilt the arm backwards (left control backward). When the container touches the ground, release the brakes to free the truck for forward movement caused by the container.




3. Rotate jib all the way till the container touches the ground. Pull away from container and rotate jib back into the transport position.



WARNING:


1. **DON'T OVER SPEED THE PUMP
1,500 RPM MAXIMUM.**
2. **DON'T DUMP ON UNEVEN GROUND.**





WARNING:
(CONTINUED)

3. **DON'T DRIVE WITH THE HOIST IN THE DUMP POSITION OR WITH THE HOOK TILTED BACK.**




MAINTENANCE

MAINTENANCE INSTRUCTIONS

WEEKLY SERVICE - (50 OPERATIONS)

1. Lubricate with grease (Refer to Lubrication Diagram)
 - Lifting hook on jib
 - Jib slide - top, bottom, and side guides
2. Check hydraulic oil level. With the hoist in the transport position (lift cylinders retracted and jib cylinder extended – see diagram on front cover) the oil level in the tank should read approximately one inch below the top of the glass sight on the temperature/sight gauge (see diagram ➔).
3. Check hydraulic hose and fittings for leaks. Also check hydraulic hose for wear. Repair and/or retighten as necessary.




MONTHLY SERVICE - (200 OPERATIONS)

1. Lubricate with grease (Refer to Lubrication Diagram)
 - Fittings on lift cylinders (quantity: 4)
 - Front pins on rear pivot joint weldment (quantity: 2)
 - Fittings on rear pivot pins, and rollers (quantity: 4)
2. Check all bolts and retighten as required.
4. Check adjustments on mast lock (safety latch) mechanism. Refer to the Mast Lock Inspection & Adjustment Instructions on page 4-7 of the maintenance section.
3. Check adjustments on jib lockout valve. Refer to the Jib Lockout Valve Inspection & Adjustment Instructions on page 4-9 of the maintenance section

YEARLY SERVICE

1. Check for proper gapping on outer tube clamp assembly. Refer to the Outer Tube Clamp Inspection & Adjustment Instructions on page 4-13 of the maintenance section.
2. Change hydraulic oil, replace hydraulic filter element, and wash out suction strainer.
3. Check main relief valve setting. Refer to the Pressure Check Instructions on page 4-11 of the maintenance section. (Pressure should be 3,250 PSI minimum).

LUBRICATION DIAGRAM



LEGEND	
GM	= GREASE MONTHLY
GW	= GREASE WEEKLY

HYDRAULIC OIL SPECIFICATION & INTERCHANGE CHART

Select an ISO grade of Premium Anti-Wear Hydraulic Oil that is optimum for your location.

HYDRAULIC OIL SELECTION CHART

ISO Grade	Ambient Temperature Range		Viscosity
	°F	°C	SUS @ 100 °F
32	-10 to 85	-23 to 29	150-170
46	10 to 110	-12 to 43	195-240

NOTE 1: Always consult your local hydraulic oil supplier for more information.

NOTE 2: Use caution when operating at or beyond the recommended temperature extremes.

NOTE 3: Do not operate the hooklift hoist when hydraulic oil temperature on tank gauge exceeds 160 °F (71 °C) as damage to hydraulic components can occur.

ISO Grade 32

Company Name	Brand Name & Grade
Castrol (BP)	Paradene 32AW
CITGO	A/W 32
Exxon	Nuto H 32
Mobil	DTE 24 (DTE 13)
Shell	Tellus 32
SUNOCO	Sun Vis 706 (816 WR)

ISO Grade 46

Company Name	Brand Name & Grade
Castrol (BP)	Paradene 46AW
CITGO	A/W 46
Exxon	Nuto H 46
Mobil	DTE 25 (DTE 15)
Shell	Tellus 46
SUNOCO	Sun Vis 747 (821 WR)

HYDRAULIC FILTER ELEMENT SPECIFICATIONS & INTERCHANGE CHART

Element Size:	3.66 φ x 8.6"
Mounting Thread:	1-12 UNF
Filtration Rating:	10 micron (Nominal)
Flow Rating:	25 GPM

Company Name	Filter Part Number
Baldwin	BT8443
Behringer	BSO92E10N25
Donaldson	P550255
Fleetguard	HF6511
Flow Ezy	FEE30-10L
FPC	FPE40-10N

Company Name	Filter Part Number
Hydac	0085MA010P
LHA	SPE25-10
Norman	410
PTI	F4E-040CCB
Purolator	20201
Zinga *	AE-10L

* Brand of Element supplied from factory on hoist.

GENERAL MAINTENANCE PARTS LIST

<u>PT. NO.</u>	<u>DESCRIPTION</u>
21P31	<u>HYDRAULIC CYLINDER 5ϕ X 40 (Lift/Dump)</u>
21P37	SEAL KIT, HYDRAULIC CYLINDER
21P69	HYDRAULIC LINE ASS'Y (REPLACEMENT)
20P28	HYDRAULIC VALVE CARTRIDGE, COUNTERBALANCE
* * * * *	
20P51	<u>HYDRAULIC CYLINDER 3ϕ X 32 (Jib)</u>
20P89	SEAL KIT, HYDRAULIC CYLINDER
20P28	HYDRAULIC VALVE CARTRIDGE, COUNTERBALANCE
* * * * *	
20P53	<u>HYDRAULIC PUMP, GEAR (2.96 CID, L.H. ROT.) - Standard</u>
20P98	<u>HYDRAULIC PUMP, GEAR (2.96 CID, R.H. ROT.) - Optional</u>
20P55	SEAL KIT, HYDRAULIC PUMP
* * * * *	
20P22	<u>HYDRAULIC FILTER, 15 GPM</u>
20P23	HYDRAULIC FILTER ELEMENT
20P64	INDICATOR GAUGE, FILTER
* * * * *	
20P05	<u>HYDRAULIC TANK, 15 GALLON</u>
20P07	STRAINER, TANK MOUNTED - 25 GPM
20P96	SIGHT GAUGE, HYDRAULIC TANK
20P97	BREATHER CAP ASSEMBY, HYDRAULIC TANK
* * * * *	

21P32 HYDRAULIC CONTROL VALVE, 2 SECT.

20P17 HYDRAULIC RELIEF VALVE CARTRIDGE (3250 PSI)

* * * * *

21P28 HYDRAULIC VALVE, 2-WAY

21P38 SEAL KIT FOR 21P28

* * * * *

90P71 WEAR PAD, 12" – (Z-CHANNEL)

00755 3/8φ LOCK WASHER

00P14 3/8-16 HEX NUT

00P68 3/8-16 x 1 1/4 FL HD SCREW (SST)

* * * * *

20H65 CLAMP LINER – (OUTER TUBE)

00P18 5/16-18 x 1 FL HD SCREW (BRASS)

* * * * *

23H54 WEAR BLOCK – (JIB)

00P18 5/16-18 x 51 FL HD SCREW (BRASS)

* * * * *

REPLACEMENT BEARING LIST

<u>PT. NO.</u>	<u>DESCRIPTION</u>
11H42	<u>PIVOT PIN (FOR 11H79 PIVOT JOINT SUB-ASSEMBLY)</u>
23H08	BRONZE BEARING; QTY: 1 PER PIN
	* * * * *
51H70	<u>MAIN PIVOT PIN (FOR 11H79 PIVOT JOINT SUB-ASSEMBLY)</u>
23H08	BRONZE BEARING; QTY: 1 PER PIN
	* * * * *
80P09	<u>ROLLER ASSEMBLY (FOR 11H79 PIVOT JOINT SUB-ASSEMBLY)</u>
23H07	BRONZE BEARING; QTY: 1 PER ROLLER
	* * * * *
21P31	<u>HYD CYLINDER 5ϕ x 40 (FOR 11H78 MAINFRAME SUB-ASSEMBLY)</u>
SPL	CYLINDER BEARINGS; CONTACT SWAPLOADER
	* * * * *

MAST LOCK INSPECTION & ADJUSTMENT INSTRUCTIONS


All SwapLoader hook-lift hoists come with a mast lock (safety latch) assembly that is located on the bottom side of the outer tube. When the jib is extended the mast lock then engages the latch bars (forks) on the pivot joint, making the jib, outer tube, and pivot joint into a continuous member for raising the container or body up into a dump mode.

With the jib fully retracted the mast lock then disengages the latch bars on the pivot joint allowing the hook-lift to enter into the mount-dismount cycle by pivoting around the front pins of the pivot joint. A properly adjusted mast lock will function smoothly and clear the latch bars on the pivot joint approximately a $\frac{1}{4}$ " (see illustrations below).

INSPECTION

The mast lock assembly comes adjusted from the factory and should provide years of trouble free operation, however there may come a time when an adjustment may be required. Prior to making any adjustments, SwapLoader recommends that you begin with inspecting all mast lock components for damage or wear (see illustrations below).

First inspect the adjustment tube and bolt on the jib; make sure nothing is missing or bent. Next, inspect the release lever and connection bar on the outer tube; look for any missing or bent components such as ears or pins. Finally, inspect the safety latch (see illustration below); again make sure there are no missing or bent components such as ears, pins, or latches. Repair or replace any missing or bent components prior to making any adjustment to the mast lock assembly; refer to the mast lock (safety latch) assembly drawing for proper part numbers and identification of the components (See Drawing No. 10H40 in the Part List pages of the manual).



ADJUSTMENT


If after inspecting all mast lock components and making any necessary repairs the gap between the mast lock and latch bars on the pivot joint is still incorrect, then an adjustment will need to be made. Please complete the following steps:

1. Retract the telescopic jib until the cylinder completely bottoms out (fully retracted).
2. Inspect the gap between the mast lock latch and the latch bar on the pivot joint. Look for a clearance of approximately 1/4" (if not proceed to steps 3-5).
3. Loosen the jam nut on the adjustment bolt.
4. Turn the adjustment bolt; counter-clockwise to increase the gap or clockwise to decrease the gap.
5. Once the 1/4" clearance is achieved, then tighten the jam nut. Make sure to hold the adjustment bolt from turning when tightening the jam nut.

Please contact your SwapLoader Distributor or SwapLoader USA should you have any questions regarding this procedure.

JIB LOCKOUT VALVE INSPECTION & ADJUSTMENT INSTRUCTIONS


All SwapLoader hook-lift hoists have a jib lockout valve (see illustration below) to prevent accidental operation of the telescopic jib, while the hoist is up in a dump mode. Because the jib lockout valve can block the flow of hydraulic oil to the jib cylinder, should the valve come out of adjustment the telescopic jib may experience a reduction in extension or retraction speed to the point of stalling out.



INSPECTION

When a noticeable loss in extension or retraction speed of the telescopic jib is experienced, the first step should be to inspect the jib lockout valve and valve mount ramp to ensure that they are adjusted properly and in good working order. The jib lockout valve is located on the inside rail of the hoist mainframe approximately two-thirds of the way back on the driver side of the hoist (see Drawing No. 11H78 in the Part List pages of the manual). Visually inspect the jib lockout valve roller and the condition of the valve ramp on the hoist pivot joint without a container on the hoist (see illustration on the next page); this is most easily performed with the hoist back in a dismount mode. If either part shows signs of wear or damage then replace or repair as needed.

With the jib lockout valve roller and valve ramp in good condition the next step is to check that the valve is positioned correctly with respect to the valve ramp. While looking at the roller end of the jib lockout valve, notice that the roller moves in and out of an end cap. With the hoist pivot joint in the down position, or horizontal to the hoist mainframe, the valve ramp should be in contact with the jib lockout valve roller. The roller should be depressed by the valve ramp so that 1/8" to 3/16" of the roller is exposed from the end cap (see illustrations above and on next page).



ADJUSTMENT

Should the jib lockout valve need adjustment the first step will be to loosen the mount bracket screws (see illustration above). Reposition the jib lockout valve with respect to the valve ramp by turning the adjustment screw on the valve mount bracket as follows:

Clockwise Adjustment – Moves the jib lockout valve closer to the valve ramp

Counter-Clockwise Adjustment – Moves the jib lockout valve away from the valve ramp

Once the valve has been moved back into proper adjustment, then tighten up the mount bracket screws.


PART NUMBER & SPECIFICATION

SwapLoader Prt. No.	Work Port Size	Spool Type	Pressure (Maximum)	Flow Rate (Maximum)
21P28	3/4-16 ORB (SAE 8)	2-Way, 2-Position N.C.	4,600 PSI (Nominal)	16 GPM (Nominal)

Please contact your SwapLoader Distributor or SwapLoader USA should you have any questions regarding this procedure.

PRESSURE CHECK INSTRUCTIONS


When performing a pressure check on a SwapLoader hook-lift hoist, we recommend that you use a calibrated pressure gauge that reads pressures up to 3,500 PSI (a 0 to 5,000 PSI range gauge is recommended). As a minimum, the gauge should have 100 PSI graduation marks (50 PSI is preferred), and a 3 inch diameter dial size (4 inch dial is preferred). The pressure gauge should be outfitted with a female JIC #4 hydraulic adapter; preferably located at the end of a 3/8 inch diameter high pressure hydraulic hose that is 2 to 3 foot in length (see illustration below).



Should you not be able to source a hydraulic gauge locally, SwapLoader can provide one at a reasonable cost (Hyd. Pressure Gauge & Hose Ass'y – Part No. 22P10).


PRESSURE CHECK STEPS

1. Locate the 90° male JIC #4 hydraulic adapter (SWL #10P37) found on the top of the hoist hydraulic control valve (see illustration below).




This 90° male #4 JIC hydraulic adapter is supplied by SwapLoader, and should be installed in the hydraulic control valve at the time of the hoist installation (see the hoist parts & operations manual).

2. Remove the female JIC #4 cap from the male JIC #4 adapter and attach the pressure gauge to the hydraulic control valve (see illustration below).



3. Start the truck and engage the P.T.O.
4. Push the lift (dump) circuit lever forward until the lift (dump) cylinders bottom out (see illustration below). Continue to push the lever forward until steps 5-6 are complete.



5. Check the gauge for the maximum developed system pressure. The SL-145 should have a reading of 3,250 PSI.
6. With the pressure check complete; release all functions and disengage the P.T.O.


Please contact your SwapLoader Distributor or SwapLoader USA should you have any questions regarding this procedure.

OUTER TUBE CLAMP INSPECTION & ADJUSTMENT INSTRUCTIONS

All SwapLoader hooklift hoists come equipped with an outer tube clamp assembly located on the bottom of the outer tube at the opening where the jib telescopes in and out (see illustration below). On SwapLoader 100 & 200 series hoist models the outer tube clamp assembly is adjustable in height.

INSPECTION

The illustration below is a typical hoist clamp assembly for the 100 & 200 series SwapLoader hoist models. For optimum performance out of your SwapLoader SL-145 hooklift the gap between the top of the jib horizontal tube and the top inside surface of the outer tube should be kept between 1/16" to 1/8" (see Section View A-A below). When a gap greater than 1/8" exists, prior to making any adjustments: inspect the clamp liner, clamp bar, and adjustment fasteners for excessive wear or damage (see Section View A-A below). Replace any parts as needed (see Drawing No. 11H77 in the Parts List pages of the manual). If the clamp liner and other components are found to be or have been brought up to satisfactory condition, but a gap greater than 1/8" exists between the inner and outer tubes; then proceed to the outer tube clamp adjustment steps below.




ADJUSTMENT

Refer to the 100 & 200 series Hoist Clamp Assembly Illustration above for the following adjustment steps:


1. Loosen the jam nuts on the clamp bar adjustment bolt.
2. Tighten the adjustment nuts equally so that the clamp bar is drawn up evenly. Be sure to keep the jib horizontal tube level; make sure the gap is even between the inner and outer tubes from left to right.
3. Once the gap between the top of the jib horizontal tube and the top inside surface of the outer tube is between 1/16" to 1/8" the jam nuts can be tightened up.


PARTS LIST



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	11H77	TELESCOPIC SUB-ASS'Y	634.83	
2	ONE	11H78	MAINFRAME SUB-ASS'Y	930.75	
3	ONE	11H79	PIVOT JOINT SUB-ASS'Y	478.46	
4	ONE	90H89	BASE HYD ASS'Y	20.52	NOT SHOWN
5	ONE	90P68	SERIAL TAG	0.01	
6	ONE	12H42	HOIST INSTALLATION KIT	26.18	NOT SHOWN
7	ONE	90H90	CHASSIS TANK CIRCUIT	69.36	NOT SHOWN
8	ONE	90H91	PUMP CIRCUIT	12.82	NOT SHOWN
9	ONE	90H72	MANUAL CONTROL ASS'Y	49.39	NOT SHOWN
10	ONE	20P53	HYD PUMP, GEAR	39.00	NOT SHOWN
				2261.32	TOTAL

 SWAPLOADER™ U.S.A. LTD.
SWAPLOADER HOIST - BASE ASS'Y
SL-145
11H80 ~ REV B



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	10H32	MAINFRAME PIN WELDMENT	5.51	
2	ONE	11H70	MAINFRAME WELDMENT	506.98	
3					
4					
5	2	21P31	HYDRAULIC CYLINDER 5ø x 40	202.00	
6	6	90P71	12" WEAR BLOCK	0.71	
7	2	00P13	3/8-16 x 1 1/4 HHCS	0.06	GR-8
8	24	00P14	3/8-16 HEX NUT	0.02	GR-8
9					
10					
11	2	01P28	3/8ø DISC-LOCK WASHER	0.01	
12	24	00P68	3/8-16 x 1 1/4 FL HD SCR	0.03	SST
13	27	00755	3/8ø LOCK WASHER	0.01	
14					
15	ONE	42H11	JIB LOCKOUT VALVE MOUNT	2.39	
16	2	00P32	3/8-16 x 1 1/4 SOC HD SCR	0.06	
17	ONE	01P20	3/8-16 x 1 3/4 SOC HD SCR	0.07	
18	2	01P08	5/16-18 x 2 HHCS	0.12	GR-8
19	2	00752	5/16ø LOCK WASHER	0.03	
20					
				930.75	TOTAL

DISC-LOCK WASHER
TORQUE SPEC'S

BOLT SIZE	SAE GR 8 ASS'Y TORQUE (FT-LBS)
3/8	50
7/16	80
1/2	120
5/8	230
3/4	380
7/8	400
1	400


NOTE:
LUBRICATE BOLT THREADS
BEFORE TORQUING THE
ASSEMBLY



MAINFRAME SUB-ASSEMBLY

SL-145

11H78 ~ REV E



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	80P09	ROLLER ASS'Y	39.26	
2	2	11H42	PIVOT PIN WELDMENT	6.83	
3	ONE	11H69	PIVOT JOINT WELDMENT	354.06	
4	2	22H76	PIVOT PIN CAP	0.72	
5	2	51H70	MAIN PIVOT PIN WELDMENT	16.90	
6	2	85H21	ROLLER RETAINER	1.04	
7	6	01P25	7/16-14 x 1 1/2 SOC HD SCR	0.05	GR-8
8	2	61H94	ROLLER SPACER	0.60	
9	4	90P03	1/8 NPT ZERK STR	0.01	
10	2	90P05	1/8 NPT ZERK 45°	0.01	
11					
12	4	01P30	1/2" DISC-LOCK WASHER	0.02	
13					
14					
15	4	00P09	1/2-13 x 1 HHCS	0.11	GR-8
16	6	01P29	7/16" DISC-LOCK WASHER	0.02	
17	2	00P73	1/2-13 x 1 1/4 FL HD SOC SCR	0.12	GR-8
18	2	00P86	1/2" COUNTERSUNK LOCK WASH	0.02	
19	ONE	23H56	JIB LOCKOUT VALVE RAMP	1.18	
				487.22	TOTAL

DISC-LOCK WASHER TORQUE SPEC'S

BOLT SIZE	SAE GR 8 ASS'Y TORQUE (FT-LBS)
3/8	50
7/16	80
1/2	120
5/8	230
3/4	380
7/8	400
1	400

NOTE:
LUBRICATE BOLT THREADS
BEFORE TORQUING THE
ASSEMBLY




PIVOT JOINT SUB-ASSEMBLY

SL-145

11H79 ~ REV D


DISC-LOCK WASHER TORQUE SPEC'S	
BOLT SIZE	SAE GR 8 ASS'Y TORQUE (FT-LBS)
3/8	50
7/16	80
1/2	120
5/8	230
3/4	380
7/8	400
1	400

NOTE:
LUBRICATE BOLT THREADS
BEFORE TORQUING THE
ASSEMBLY



DETAIL A-A

PARTS LIST											
ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS	ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	11H76	JIB WELDMENT	238.65		14	2	00755	3/8 ϕ LOCK WASHER	0.01	
2	ONE	11H73	OUTER TUBE WELDMENT	269.16		15	2	00P80	3/4-10 x 5 HHCS	0.81	GR-8
3	ONE	10H08	1 ϕ CYLINDER PIN	1.73		16	2	00P17	3/4-10 HEX NUT	0.20	GR-8
4	ONE	10H40	SAFETY LATCH ASSEMBLY	42.24		17	8	00P18	5/16-18 x 1 FL HD SCR	0.01	BRASS
5	ONE	62H11	COVER PLATE	0.94		18	4	00P13	3/8-16 x 1 1/4 HHCS	0.06	GR-8
6	ONE	23H46	1 1/4 ϕ CYLINDER PIN	2.50		19	2	00786	3/4 ϕ FLAT WASHER HT	0.05	F-436
7	2	20H19	CYLINDER RETAINER	0.60		20	ONE	20P51	HYD CYLINDER 3 ϕ x 32	66.00	
8	2	20H21	SPACER	0.20		21	2	00P72	3/4-10 LOCKING HEX NUT	0.20	GR-C
9	ONE	20H64	CLAMP BAR	7.76		22	2	00P73	1/2-13 x 1 1/4 FL HD SOC SCR	0.12	
10	ONE	20H65	CLAMP LINER	0.21		23	2	00P86	1/2 ϕ COUNTERSUNK LOCK WASH	0.02	
11	2	00P03	3/8-16 x 3/4 HHCS	0.04	GR-8	24	ONE	23H54	WEAR BLOCK	0.19	
12	ONE	00P05	EXT RET RING FOR 1 ϕ	0.01		25	4	01P28	3/8 ϕ DISC-LOCK WASHER	0.01	
13	2	61H97	CYLINDER PIN CAP	0.31						634.87	TOTAL




SWAPLOADER™
U.S.A. LTD.

TELESCOPIC JIB SUB-ASSEMBLY

SL-145


11H77 ~ REV B



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	20H93	LATCH STOP	0.10	
2	4	00P25	1/16 ϕ x 3/4 COTTER PIN	-	
3	2	00P27	1/8 ϕ x 1 1/4 COTTER PIN	0.01	
4	2	00P24	5/8-11 HEX NUT	0.11	GR-8
5	2	01P18	5/8-11 x 3 HHCS	0.35	GR-8
6	2	00P22	3/4 ϕ x 2 1/2 CLEVIS PIN	0.33	
7	2	00P28	EXT. RETAINER RING FOR 3/4 ϕ	0.01	
8	2	20H69	RELEASE LEVER	4.98	
9	ONE	10H34	CONNECTION BAR WELDMENT	10.60	
10	2	10H33	SAFETY LATCH WELDMENT	6.37	
11	4	00P26	1/8 ϕ x 1 COTTER PIN	0.01	
12	4	00P23	1/4 ϕ x 1 3/4 CLEVIS PIN	0.03	
13	2	90P04	7/8 ϕ x 6 SPRING	0.38	
14	2	10H35	TAKE UP WELDMENT	0.25	
15	4	00P14	3/8-16 HEX NUT	0.02	GR-8
				36.62	TOTAL


	SAFETY LATCH ASSEMBLY
	SL-145
	10H40 ~ REV C




HYD TANK
(REF)

PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	11H81	DECAL ASSEMBLY	-	NOT SHOWN
2	ONE	11H82	PARTS & OPERATIONS MANUAL	-	NOT SHOWN
3	8	22H38	FRONT BRACKET	1.72	
4	2	22H39	REAR BRACKET	2.10	
5	3	00752	5/16 ϕ LOCK WASHER	0.04	
6	4	00755	3/8 ϕ LOCK WASHER	0.05	
7	26	00784	1/2 ϕ FLAT WASHER H.T.	0.02	F-436
8	26	00P15	1/2-13 x 1 3/4 HHCS	0.15	GR-8
9	4	00P13	3/8-16 x 1 1/4 HHCS	0.13	GR-8
10	4	00P14	3/8-16 HEX NUT	0.10	GR-8
11	3	00P19	5/16-18 x 2 3/4 HHCS	0.13	GR-8
12	3	00P20	5/16-18 HEX NUT	0.09	GR-8
13	26	00P35	1/2-13 LOCKING HEX NUT	0.06	GR-C
14	2	10P28	HEX BOLT 5/16 ϕ x 1 1/4	0.03	HEX-T2
15	2	10P29	COVER PLATE	0.10	TCP-T2
16	2	10P30	CLAMP HALF ASSEMBLY	0.04	T2050
				26.18	TOTAL



SECTION A-A



SECTION B-B





SWAPLOADER™
U.S.A. LTD.

HOIST INSTALLATION KIT ASSY

SL-145

12H42



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	10H51	VALVE MOUNT BRACKET WDMT	8.24	
2	ONE	21P32	HYD VALVE ASS'Y	27.00	
3	2	20P08	REMOTE VALVE CONTROL HANDLE	2.80	
4	ONE	20P09	CONTROL HANDLE MOUNT CONSOLE	4.05	
5	2	20P10	BONNET CONNECTION KIT	0.50	
6	2	20P15	CONTROL CABLE 84" LG	1.75	
				49.39	TOTAL

NOTE:
A 2 SECTION CONTROL VALVE ASS'Y IS SHOWN. A 3 SECTION CONTROL VALVE ASS'Y IS REQUIRED WHEN A STABILIZER IS UTILIZED




MANUAL CONTROL ASS'Y - 2 SECTION


SL-105/145/180

90H72 ~ REV A

PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	10P39	ADP, HYD MJIC / ORB	0.30	6400-8
2	2	10P43	ADP, HYD MJIC BHD	0.30	2700-LN-8
3	6	11P23	ADP, HYD MJIC / ORB 90°	0.30	6801-8
4	ONE	12P51	HOSE ASS'Y 1/2 HP x 42	2.05	
5	ONE	12P52	HOSE ASS'Y 1/2 HP x 38	1.90	
6	ONE	12P53	HOSE ASS'Y 1/2 HP x 21	1.26	
7	ONE	12P54	HOSE ASS'Y 1/2 HP x 17	1.11	
8	ONE	12P55	HOSE ASS'Y 3/8 HP x 29 1/2	1.43	
9	ONE	12P56	HOSE ASS'Y 3/8 HP x 74	2.85	
10	ONE	12P57	HOSE ASS'Y 3/8 HP x 105	3.82	
11	2	12P58	ADP, HYD MJIC BHD TEE	0.30	2704-LN-8
12	ONE	21P28	HYDRAULIC VALVE	2.20	
13	ONE	90H74	NYLON HOSE SLEEVE, 1 1/2" x 60	0.30	
				20.52	TOTAL





SWAPLOADER™
U.S.A. LTD.

HYD. SUB-ASSY - BASE CYLINDER CIRCUIT

SL-145

90H89



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	ONE	10P26	ADP, HYD MP / MP	0.70	5404-20-16
2	ONE	10P37	ADP, HYD MJIC / MP 90°	0.30	2501-4-4
3	ONE	10P38	ADP, HYD JIC CAP	0.10	304-C-4
4	3	10P44	ADP, HYD MJIC / FMJIC SVL 90°	0.30	6500-8
5	ONE	10P45	ADP, HYD MJIC / ORB 90°	0.30	6801-8-10
6	ONE	10P53	HYD TUBING - VALVE LOWER	2.26	
7	ONE	10P54	HYD TUBING - VALVE UPPER	2.33	
8	ONE	11P08	ADP, HYD MJIC / ORB	0.30	6400-8-10
9	2	11P20	WORM GEAR CLAMP	0.10	HSS16
10	2	12P16	ADP, HYD MJIC / ORB LL 90°	0.30	6801-LL-8
11	2	12P17	ADP, HYD ORB / FM ORB	0.20	6410-10-8
12	ONE	12P21	ADP, HYD MP / FP	0.20	1 x 3/4
13	ONE	12P22	ADP, HYD HOSE INS / MP	0.30	ST5
14	ONE	12P23	ADP, HYD HOSE INS / ORB 90°	0.60	4601-12
15	ONE	12P29	HOSE 3/4 LP x 24	0.88	
16	ONE	12P53	HOSE ASS'Y 1/2 HP x 21	1.26	
17	ONE	12P59	HOSE ASS'Y 1/2 HP x 20	1.22	
18	ONE	20P05	HYDRAULIC TANK - 15 GAL	54.20	SEE NOTE
19	ONE	20P22	HYDRAULIC FILTER	2.30	
20	ONE	20P64	INDICATOR GAUGE	0.01	
				69.36	TOTAL

NOTE:


HYD TANK ASS'Y CONSISTS OF:
TANK WELDMENT, TANK MOUNTED STRAINER,
SIGHT GAUGE, FILLER/BREATHING CAP,
MAGNETIC DRAIN PLUG, AND PORT PLUGS.



HYD. SUB-ASS'Y - CHASSIS TANK CIRCUIT


SL-145

90H90



PARTS LIST



ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	10P21	1 1/2" T-BOLT CLAMP	0.10	TBC-150
2	ONE	10P32	ADP, HYD MJIC / ORB 45°	0.30	6802-10-12
3	ONE	10P35	ADP, HYD MJIC / ORB	0.30	6400-10-12
4	ONE	10P61	HOSE ASS'Y 1/2 HP x 106	4.42	
5	ONE	12P18	ADP, HYD HOSE INS / ORB	0.40	4604-16
6	ONE	12P19	ADP, HYD HOSE INS / MP	0.30	ST10
7	ONE	12P20	ADP, HYD MP / FP	0.30	1 1/4 x 1
8	ONE	12P28	HOSE 1 LP x 120	6.60	
				12.82	TOTAL


SWAPLOADER™
U.S.A. LTD.

HYD. SUB-ASS'Y - PUMP CIRCUIT


SL-105/145/180

90H91



PARTS LIST

ITEM	QTY	P/N	DESCRIPTION	WT-lb/ea	REMARKS
1	2	90P07	OPR & SERV MANUAL		
2	2	90P08	HOIST-BODY SPEC		
3	ONE	90P09	HYD OIL SPEC		
4	ONE	90P10	HYD OIL FLAMMABLE		
5	2	90P11	HOIST FALLING		
6	ONE	90P12	LEVER CONTROL		
7	ONE	90P13	SAFETY INSTRUCTIONS		
8	2	90P14	SWAPLOADER - JIB		
9	4	90P67	SL-145		
10	ONE	90P18	RELIEF VALVE		
11	ONE	90P78	HIGH-PRESSURE FLUID		
12	2	91P06	LUBRICATION POINTS		
				TOTAL	



OPTIONS

ELECTRIC OVER HYDRAULIC VALVE

(22P58)

INSTALLATION INSTRUCTIONS FOR SL-145

- 1.) Review all directions and diagrams provided before starting the Electric over Hydraulic Valve Installation.
- 2.) Mount the 22P58 EHV to the hoist mainframe and attach all hoses, hose clamp assemblies and fittings as shown on drawing 91H22, 91H23 & 91H25 (also see Figures 1 & 2).




Figure 2




Figure 1

ELECTRIC OVER HYDRAULIC VALVE

(22P58)

- 3.) Route control harness from valve into the truck cab. Determine the best location in the cab for the control box location and install with mounting screws (included). The location should be such that the controls can be easily reached while operating the truck.





Figure 3

- 4.) Insert power adapter into 12V outlet or hardwire to 12V battery.



SEE NOTE 1
SEE NOTE 1


PARTS PER 12H80				
ITEM	QTY	PART #	DESCRIPTION	WT-lb/ea
1	1	11H81	DECAL ASSEMBLY	0.01
2	1	11H82	PARTS & OPERATION MANUAL	0.01
3	8	22H38	FRONT BRACKET	1.72
4	2	22H39	REAR BRACKET	2.10
5	30	00784	Ø1/2 FLAT WASHER HT	0.02
6	30	00P15	1/2-13 UNC x 1 3/4HHCS	0.15
7	30	00P35	1/2-13 UNC LOCK NUT	0.06
TOTAL				24.88

SL-145 HOIST INSTALLATION KIT (12H80)
(FOR ELECTRIC CONTROL VALVE)

SHOP NOTES:
1. 11H81 (DECAL ASSEMBLY) AND 11H82
(PARTS AND OPERATION MANUAL) NOT
SHOWN.


SWAPLOADER™ USA, LTD.
HOIST INSTALLATION KIT - EHV
SL-145
12H80


PARTS PER 91H22				
ITEM	QTY.	PART #	DESCRIPTION	WT-lb/ea.
1	2	10P21	Ø1 1/2 T-BOLT CLAMP	0.10
2	1	10P32	ADP, HYD M/JC/ORB 45°	0.30
3	1	10P61	HOSE ASS'Y 1/2 HP x 106	4.42
4	1	12P18	ADP, HYD HOSE INS/ORB	0.30
5	1	12P19	ADP, HYD HOSE INS/MP	0.30
6	1	12P20	ADP, HYD MP/FP	0.30
7	1	12P28	HOSE 1 LP x 120	6.60



SWAPLOADER™ U.S.A. LTD.
EHV SUB-ASS'Y - PUMP CIRCUIT
100 SERIES
91H22

PARTS PER 91H25				
ITEM	QTY.	PART #	DESCRIPTION	WT-lb/ea
1	2	10P44	ADP, HYD MJC/FMJIC SVL 90°	0.30
2	2	10P63	HEX BOLT 5/16 x 1 3/4	0.03
3	2	10P64	COVER PLATE	0.10
4	2	10P65	CLAMP HALF ASS'Y	0.04
5	1	12P53	HOSE ASS'Y 1/2 HP x 21 W/ FF & FF 45	1.26
6	1	12P59	HOSE ASS'Y 1/2 HP x 20 W/ FF & FF 45	1.22
7	2	13P25	HOSE ASS'Y 08-08FJ45/08FJ 58	2.72





EHV SUB-ASS'Y - VALVE HOSE CIRCUIT

SL-145

91H25 ~ REV. A



1800 NE Broadway Avenue, Des Moines, Iowa, U.S.A. 50313-2644
Phone: (515) 266-3042 • Fax: (515) 313-4426 • Toll Free: (888) 767-8000
E-Mail: sales@swaploader.net • Web Site: www.swaploader.com