




Model SL-95

Parts and Operations Manual



Hoist Serial Number: _____

TABLE OF CONTENTS

I. INTRODUCTION

Letter to Customer
Warranty Statement
Safety Suggestions

II. INSTALLATION

Initial Inspection
Hoist Installation
Controls Installation
Hydraulic Tank Installation
P.T.O. Selection
Pump Installation
Start Up Procedure

III. OPERATION

Loading a Container
Dumping a Container
Placing a Container on the Ground

IV. MAINTENANCE

Weekly Service (50 Operations)
Monthly Service (200 Operations)
Yearly Service
Hydraulic Oil Specifications

V. PARTS LIST

Final Assembly
Mainframe Subassembly
Rear Pivot Subassembly
Telescopic Jib Subassembly
Safety Latch Assembly
Manual Control Assembly, 2 Section
Final Hydraulic Assembly
Hydraulic Subassembly - Cylinder Circuit
Hydraulic Subassembly - Pump Circuit
Decal Assembly

VI. OPTIONS

Body Prop

INTRODUCTION

SWAPLOADER U.S.A., LTD.

TO THE CUSTOMER

Your new SwapLoader was carefully designed and manufactured to give years of dependable service. To keep it operating efficiently, read the instructions in this manual thoroughly. It contains detailed descriptions and instructions for the efficient operation and maintenance of your SwapLoader. Each section is clearly identified so you can easily find the information that you need. Read the Table of Contents to learn where each section is located. All instructions are recommended procedures only.



Throughout this manual you will come across "Dangers," "Warnings," or "Cautions" which will be carried out in bold type and preceded by the symbol as indicated to the left. Be certain to carefully read the message that follows to avoid the possibility of personal injury or machine damage.

Record your SwapLoader serial number in the appropriate space provided on the title page. Your SwapLoader dealer needs this information to give you prompt, efficient service when you order parts. It pays to rely on an authorized SwapLoader Distributor for your service needs. For the location of the Distributor nearest you, contact SwapLoader.

NOTE: It is SwapLoader's policy to constantly strive to improve SwapLoader products. The information, specifications, and illustrations in this publication are based on the information in effect at the time of approval for printing and publishing. SwapLoader therefore reserves the right to make changes in design and improvements whenever it is believed the efficiency of the unit will be improved without incurring any obligations to incorporate such improvement in any unit which has been shipped or is in service. It is recommended that users contact an authorized SwapLoader Distributor for the latest revisions.

LIMITED WARRANTY STATEMENT

Effective October 1, 2004

SwapLoader U.S.A., Ltd., (SwapLoader), warrants to the original purchaser of any new SwapLoader product for a period of thirty-six (36) months from the date of Retail Sale by an authorized SwapLoader distributor or service center, that such products are free of defects in material and workmanship. SwapLoader will, at its discretion, either repair the defective parts or replace them with equivalent parts, subject to the conditions below unless deferred warranty is approved by SwapLoader U.S.A., Ltd.

- Replacement or repair of parts will be provided for 36 months on SwapLoader products, subject to any applicable federal, state or local taxes. Labor charges authorized by the SwapLoader Warranty Department are covered for a period of 90 days from the date of Retail Sale by an authorized SwapLoader Distributor or service center.
- Defective parts must be reported to SwapLoader within 30 days of discovery on a SwapLoader warranty claim report form.
- Warranty Registration Card must be returned within 15 days of Retail Sale of SwapLoader hoist to SwapLoader, Des Moines, Iowa. If unit has not been registered, then the warranty start date will revert to the original factory invoice date.
- Warranty shall not apply if the equipment is operated at capacities in excess of factory recommendations.
- The warranty covers only defective material and workmanship. It does not cover depreciation or damage caused by normal wear and tear, accident, mishap, untrained operators, or improper or unintended use. The owner has the obligation of performing routine care and maintenance duties as stated in SwapLoader's written instructions, recommendations, and specifications. Any damage resulting from owner/ operator failure to perform such duties shall void the coverage of this warranty. The cost of labor and supplies associated with routine maintenance will be paid by the owner.
- In no event will SwapLoader, the SwapLoader distributor or any company affiliated with SwapLoader be liable for business interruptions, costs of delay, or for any special, indirect, incidental or consequential costs or damages. Such costs may include, but are not limited to loss of time, loss of revenue, loss of use, wages, salaries, commissions, lodging, meals, towing, hydraulic fluid, travel, mileage, or any other incidental costs.
- SwapLoader is not responsible for the removal or replacement of accessories (fenders, toolbox, etc.).
- Warranty service must be performed by a distributor or service center authorized by SwapLoader to sell and/or service SwapLoader products, which will use only new or remanufactured parts or components furnished by SwapLoader U.S.A., Ltd.
- Warranty is expressly void if seal on the main relief control valve has been broken.
- SwapLoader will ship the replacement part by the most economical, yet expedient means possible. Expedited freight delivery will be at the expense of the owner.
- Warranty is expressly void if serial number plate or stamping is tampered with.

IT IS EXPRESSLY UNDERSTOOD AND AGREED THAT THERE ARE NO WARRANTIES MADE BY THE MANUFACTURER OR ITS AGENTS, REPRESENTATIVES OR DISTRIBUTORS, EITHER EXPRESSED, IMPLIED, OR IMPLIED BY LAW, EXCEPT THOSE EXPRESSLY STATED ABOVE IN THIS STANDARD LIMITED WARRANTY AGAINST DEFECTS IN MATERIAL AND WORKMANSHIP. THE MANUFACTURER AND ITS AGENTS, REPRESENTATIVES AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

SAFETY SUGGESTIONS

1. Do not operate or service this equipment until you have been properly trained and instructed in its use and have read the operation and service manual.
2. Do not operate this equipment on uneven ground.
3. Do not drive with the container in a dump position or with the hook to the rear.
4. Do not exceed 1,500 Engine RPM when operating the Power Take Off (P.T.O.). Never leave the P.T.O. in gear while transporting.
5. The hoist must be used with containers that properly fit the hook and rear holddowns. The container specifications must match the hoist specifications.
6. Keep the containers and hoist in good working order. **DO NOT** use if repairs are needed. Perform periodic inspections and maintenance as required by the maintenance section of the operator's manual.
7. Make sure work area is clear of people and obstacles prior to dumping or unloading containers. SwapLoader strongly recommends that a back up alarm be installed on the truck chassis. The operation of the hook hoist is that the truck is backed up to the body to pick it up and so there is a potential pinch point between the body and the hook.
8. Any container which is on the hoist **MUST** be unloaded prior to performing any repairs or maintenance to the hoist. Also, **DO NOT** allow any person to work on or be under the hoist in a raised position without first installing adequate safety blocks to eliminate all possibility of the hoist accidentally lowering. SwapLoader strongly recommends that if possible the container should be dismounted from the hoist prior to performing any maintenance to the hoist.
9. It is the responsibility of the owner and/or installer to insure that any additional safety devices required by state or local codes be installed on the SwapLoader Hoist and/or Truck Chassis.

INSTALLATION

INITIAL INSPECTION

When the SwapLoader hoist is received from the factory, you should inspect the hoist for damage, which may have occurred in shipment. If damage has occurred, you should contact the shipper immediately. Be sure to note any damage or missing items on bill of Lading.

You should then check the hoist to insure you have received all the parts as indicated by the Packing List and the Ship Loose Box List.

If you have any problems, shortages, or questions, please contact SwapLoader U.S.A., Ltd. immediately.

GENERAL INSTALLATION PROCEDURE

The installation of the SwapLoader on a truck chassis will generally follow these steps:

1. Install hoist assembly onto truck chassis.
2. Mount the hydraulic control valve to the hoist and install the hydraulic plumbing from the control valve to the hydraulic cylinders. Then install the control levers in the cab and route the control cables to the hydraulic control valve assembly.
3. Install the hydraulic tank, hydraulic filter, and hydraulic plumbing between the hydraulic tank and the control valve assembly.
4. Select and install the P.T.O. on the truck transmission. (Note: This can be done prior to hoist installation on the truck chassis.)
5. Install the hydraulic pump and the plumbing from the pump to the hydraulic tank and control valve assembly.
6. Fill the hydraulic tank with oil, bleed the air from the pump suction line, and start up the unit.

Although SwapLoader attempts to include the mounts and attaching fasteners with each hoist unit, your particular installation may require some additional mounts or modifications. If you have problems with your installation, please contact SwapLoader at 1-888-767-8000, as we may be aware of another customer who has installed a SwapLoader on a similar truck chassis.

HOIST INSTALLATION TO TRUCK CHASSIS

1. Place the SL- 9 5 hoist assembly on the truck chassis. The truck chassis mounting surface should be flat without any steps or protrusions. If necessary shim bars need to be added to ensure a flat surface on which to support hoist. The truck chassis should meet the following minimum specifications (See Figures A & B):

RBM for each frame channel: 350,000 in.-lb.

Total RBM: 700,000 in.-lb.

Minimum clear frame rail for mounting: 130" (See Fig. A)

Front Axle Cap: 4,000 lb. (Min)

Total Rear Axle Capacity: 9,000 lb. (Min)

CA Dim: 78" to 96" (96" preferred)




Figure A

Note: The above specifications are a minimum requirement. It is the responsibility of the owner/operator to ensure the completed chassis meets or exceeds all federal, state, and local regulations. Also, the hoist should not be used to lift and haul any load that exceeds the load rating of any of the individual components of the completed chassis (tires, axles, suspension, etc.)

The clear frame dimension indicated in the picture above allows for the overall length of the hoist plus 5 inches for cab clearance and rear light bar mounting. Extra frame length may be needed to allow for mounting additional accessories (e.g. Cab Guard, Tarper, Light Kit, etc.). For example, when mounting a light kit on a truck with a long CA, check that the hoist and the light kit are positioned far enough back to eliminate any interference between the fender and the light kit. You should also consider the final weight distribution with regard to the bridge code when positioning the hoist.

2. There are two types of mount brackets used on the Model SL-95 hoist as indicated in Drawing No. 11H19. They are the front mount brackets (Pt. No. 22H38), and the rear mount brackets (Pt. No. 22H39).

Locate the mount brackets on the side of the hoist as indicated in Figure C. These dimensions are flexible because of possible interference with chassis components. Also allow for mounting the control valve assembly and the hydraulic tank. You should consult the truck chassis supplier for any limitations regarding drilling mount holes in the truck chassis frame rails. Typically, the holes must be at least 2 3/4" from the top of the truck chassis rails (Reference figure C & D).

Once the locations of the mount brackets have been determined, use the mount brackets as a template for marking the mounting holes in the truck chassis frame rails. Drill the 17/32 diameter holes required and attach the brackets to the truck chassis with the 1/2-inch diameter bolts, washers, and locking hex nuts provided. Torque to 110 ft.lbs.

3. Weld the mount brackets to the hoist mainframe as indicated on Figures C thru D. You may need to modify the mount brackets or add shim plates to allow for variances in the width of the truck chassis as well as to allow for top rivets, stepped channels, etc.




Figure C





Figure D

Note: Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be connected as close as possible to the part being welded to avoid the possibility of arcing across bearings, gears, etc.

Note: The hoist mainframe is made from high strength low alloy steel. Use an appropriate welding process.

CONTROLS INSTALLATION - MANUAL

1. Attach the valve mount bracket (Pt. No. 10H51) to the mainframe as indicated on Dwg. No. 90H64 with the fasteners provided.
2. Mount the hydraulic control valve assembly (Pt. No. 20P39) to the valve mount bracket as shown on Drawing No. 90H64 with the fasteners provided.
3. Install the hydraulic adapters and connect the hydraulic tubing (Pt. Nos. 11P09, 11P10, 11P11 and 11P12) to the control valve assembly as indicated on Drawing No. 90H27. The tubing should be supported by the clamp assemblies that are provided in the Loose Parts Box (See Drawing 90H25).
4. Determine the best location in the cab for the control levers (Pt. No. 20P08). The location should be such that the controls can be easily reached while operating the truck. A control lever console (Pt. No. 20P09) is provided to facilitate the mounting of the control levers.
5. Assemble and install the control lever console (See diagram below). Typically the console is fastened to the floor of the cab and the control cables are routed through additional holes drilled in the floor. Your particular installation may require that additional brackets be fabricated or other modifications made.




6. **Attach the control cables to the control levers and route the cable through the holes in the cab. Install the control levers in the console. Levers should be installed such that when the levers are pushed forward the control cable is extended. See Drawing No. 90H64 (Manual Control Assembly) for control lever orientation.**
7. **Route the cables to the control valve location and attach them to the control valve with the bonnet connection kits provided (Pt. No. 20P10). See the following instruction sheet for installation procedures. The control cables supplied are 84 inches long. Your particular mounting may require different length control cables, which can be purchased locally or through Swaploader. Take proper care when routing the control cables, as a good cable path is essential for a proper operating system. Keep bends in the cable path to a minimum and be as generous as possible. Under no circumstances should any bend be tighter than an 8" radius. Protect the cable from heat above 225 degrees F. and avoid hot areas such as exhaust pipes, etc.. Protect the cable from physical damages such as pinching or crushing, and do not use cable supports, which may crush or deform the cable. Allow room for flexing where the cable is attached to moving parts of the equipment, so that the cable is neither kinked nor stretched.**

INSTALLATION PROCEDURE FOR A HYDRAULIC CONTROL CABLE TO HYDRAULIC VALVE WITH BONNET CONNECTION KIT



1. Turn .750-16 UNF Jam Nut entire length of Threaded Hub back over the Cable. Place Flange onto Sleeve.
2. Turn Flange/Sleeve Assembly entire length of Threaded Hub back over the Cable.
3. Turn .250-28 UNF Jam Nut onto Threaded Rod until it bottoms.
4. Turn Terminal Eye onto Treaded Rod until it bottoms against Jam Nut. (Minor adjustments may be necessary to align Terminal Eye with spool yoke.)
5. Slide the Terminal Eye into yoke on spool and align the holes. Insert Clevis Pin through yoke and Terminal Eye holes. Install Retaining Ring into groove between Terminal Eye and one side of the Yoke.
6. Now, with the Cable attached to the valve and control head, turn the Flange/Sleeve Assemble back onto the Threaded Hub until it is flush with the valve face. When turning on the Flange/Sleeve Assembly, make sure that the control head remains in neutral.
7. Thread the .750-16 UNF Jam Nut back over Threaded Hub and tighten against the Sleeve to lock in position.
8. Bring Flange into position on bolt assembly to valve housing.

NOTE: FOR WORK SECTION NEXT TO INLET COVER, USE SPACER KIT.



HYDRAULIC TANK INSTALLATION

1. Select a location to mount the hydraulic tank. Reference Figure E or Drawing No. 90H64 for the suggested location of the hydraulic tank to the rear of the control valve assembly on the left-hand side of the truck. The hydraulic hoses have been sized for the tank to be mounted in this general area. The tank can be located on the right-hand side or behind the cab, if necessary, which means longer hoses may be required.
2. Drill four (4) holes for 1/2-inch diameter bolts (provided) in the mount angle of the hydraulic tank (two per angle) and the frame rails of the truck chassis. Mount the hydraulic tank and install the hydraulic filter. Install the hydraulic return hose and the hose barb fitting between the filter and the control valve assembly as shown on Drawing No. 90H26. The hose length can be shortened if necessary. Secure the hose to the barb fittings with the hose clamps provided.



SECTION A-A

Figure E

P.T.O. SELECTION

The next step is to select and install a direct drive type P.T.O. to the transmission. Please contact your local truck equipment representative for the correct unit sized on the following criteria:

P.T.O. Torque Rating:	80 ft.-lbs. (See Note 1)
Power at 1500 RPM:	23 H.P. (See Note 1)
Output Flange:	SAE B 4 Bolt
Hydraulic Pump Spined Shaft Specifications:	7/8 – 13T 16/32 D.P.
Hydraulic Pump Rotation:	L.H. As provided (See Note 2). The hydraulic pump rotation can be reversed to R.H. by a qualified hydraulic technician or it can be sourced through Swaploader.
Ratio of Pump RPM to Engine RPM:	80% to 100%

NOTE 1: P.T.O. torque and power requirements are based on the unit operating at main relief pressure. Normal operating pressure will be less.

NOTE 2: P.T.O. output rotation will need to be R.H. (clockwise) as viewed looking at output flange of P.T.O. for a L.H. Pump.

NOTE 3: Do not operate pump at speeds over 1500 R.P.M.



NOTE 4: Always disengage the P.T.O. after each operating cycle.

PUMP INSTALLATION

1. Install the hydraulic pump to the P.T.O. (Bolts are not provided).
2. Install the hydraulic fittings into ports on the hydraulic pump as shown on Drawing No. 90H26.
3. Connect the suction hose assembly to the hydraulic tank (1" I.D. hose) and route to the hydraulic pump in as short and straight line as possible. Be sure to route the hose clear of exhaust components and of the drive shaft. Extra hose is provided so the hose can be shortened to an appropriate length. Install the hose on the hose barb fittings at the tank and at the pump and secure with the hose clamps provided.

NOTE: Prior to startup, this hose must be filled with oil.

4. Connect pressure hose assembly (1/2 inch I.D. hose) to control valve inlet and route to the pump the same as the suction line. This hose is provided with only one fitting, so the hose can be shortened to appropriate length. Remove the hose and shorten as required. After the hose has been shortened, lubricate the insert threads of the fitting and the I.D. of the hose. Measure 1 3/16 inches from the end of the hose and mark the hose for the socket depth. Screw hose into the socket (left-hand thread) to the depth marked on the hose. Screw insert in socket until insert touches the socket. Clean the inside of the hose assembly by either blowing clean compressed air through it or by flushing it. Install the completed hose assembly to the inlet port of the control valve assembly and the outlet port of the hydraulic pump.



5. Tie up the pressure and suction hoses as necessary. Again, be sure the hoses are routed to avoid exhaust components and to stay clear of the drive shaft.

START UP PROCEDURE

1. Fill the hydraulic tank with hydraulic oil (see oil specification in Maintenance Section.)
2. Prime the pump by loosening the clamp on the suction hose at the pump. Pull the hose back off the fitting till the air is bled from the line. Push the hose back on the fitting and retighten the clamp.
3. Engage the P.T.O. and run the pump at idle (700 to 900 RPM). Operate the cylinders at full stroke five to ten times to bleed the air from the lines and cylinders. The cylinders were filled with oil during testing at the factory, but some seepage may have occurred during shipping and installation. Refill the hydraulic tank, if needed, during this sequence and do not let the pump run without oil.
4. Check for leaks and tighten fittings as necessary.
5. Verify the movement of the control levers corresponds to the movement of the cylinders per Figure A.




FIG A

6. Install all safety decals and product decals per Drawing No. 11H20 after final installation and painting have been completed. The factory prior to shipment of a hoist, will install some decals that have a premask layer. The premask will need to be removed after painting the hoist. It is very important when removing the premask not to pull the premask out and away from the decal at a 90° angle, but instead pull the premask straight down at a 180° angle to the decal surface. Should problems occur with the premask pulling the decal loose, wet the tack side of the premask with water via a spray bottle to weaken the adhesive bond, while pulling straight down on the premask.

7. Fill out pre-delivery checklist and warranty card and mail to SwapLoader U.S.A., Ltd.

NOTE: Failure to fill out and return warranty card within 15 days of installation may possibly void the warranty.





CAUTION: The SwapLoader hoist must be used with bodies or containers that properly fit the front hook and the rear hold-downs (See figure S025). If possible, pick up one of the containers that will actually be used with the SwapLoader hoist and verify the following:

- Outside dimensions of the long sills match the guiding rollers on the hoist.
 - The front hook dimensions are correct for the hoist.
 - The rear hold-downs of the container latch into the hold-downs on the hoist.
 - Check for any interference between the container and any part of the hoist (i.e.: Hydraulic tank, hydraulic tubing or hose, hydraulic valve, etc.)
-

NOTE:

THE INTENT OF THIS DRAWING IS TO PROVIDE THE CRITICAL SUBFRAME DIMENSIONS TO ENSURE PROPER COMPATIBILITY WITH THE SWAPLOADER HOOK LIFT HOIST. IT IS THE RESPONSIBILITY OF THE SUBFRAME SUPPLIER TO PROVIDE A SUBFRAME WHICH WILL PROPERLY SUPPORT THE BODY / CONTAINER AS IT IS USED WITH THE HOOK LIFT HOIST.



6.0000

BODY LATCH
BAR 2 x 1/2

A-FRAME LENGTH	"D" DIM
10'-0"	12
17'-0" & 10003	30 11/16

NOTE


1. MIN LENGTH FOR JO FULLY EXTENDED
2. SERIES 100 SUBFRAMES FIT THE FOLLOWING SWAPLOADER MODELS:
SL-95
SL-125 (SN 800512 & ABOVE)

MIN LENGTH : 141 (SL-125)
: 171 (SL-95)

SEE NOTE 1


AS REQ

SUB-FRAME DIMENSION
SERIES 100
S-075



SWAPLOADER[®]

U.S.A. LTD.



TOOLBOX

Aluminum (10H92) / Steel (11H12)


INSTALLATION INSTRUCTIONS


1. Review all directions and diagrams provided before starting toolbox installation.
2. Position toolbox brackets [Part No. 10H88] on truck chassis.
(NOTE: toolbox has an envelope of 18"x18"x36". See Fig. 1 for hole dimensions.)
3. Mark position of mounting holes through brackets onto truck chassis. Remove brackets and drill 9/16" dia. holes.
4. Mount toolbox brackets using fasteners provided (See Fig. 1).
5. Position toolbox [Part No. 90P27 or 90P37] on brackets. (NOTE: toolbox hinge should be on the forward, bottom edge.)
6. Mark position of mounting holes through brackets onto toolbox. Remove toolbox and drill 9/16" dia. holes.
7. Mount toolbox to brackets using fasteners provided (See Fig. 1).

TOOLBOX

Aluminum (10H92) / Steel (11H12)


MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	2	10H88	18" TOOLBOX BRACKET	11.34
2	2	22H71	TOOLBOX RUBBER SPACER (ALUMINUM TOOLBOX ONLY)	.27
3	1		18 X 18 X 36 TOOLBOX	
		90P27	ALUMINUM TOOLBOX	50.00
		90P37	STEEL TOOLBOX	72.00
4	8	00784	1/2 DIA. FLAT WASHER H.T.	.07
5	4	00P15	1/2-13 UNC X 1-3/4 HEX HEAD BOLT	.23
6	8	00P35	1/2-13 UNC METAL LOCKING NUT	.15
7	4	00P75	1/2-13 UNC X 1-1/2 SOCKET BUTTON HEAD BOLT	.12
8	4	00P76	1/2 DIA. NYLON FLAT WASHER (ALUMINUM TOOLBOX ONLY)	-
ALUMINUM TOOLBOX TOTAL				76.38
STEEL TOOLBOX TOTAL				97.84





SWAPLOADER[®]

U.S.A. LTD.





FENDER ASSEMBLY, SINGLE AXLE

Aluminum (10H93) / Steel (11H13)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting fender installation.
2. Center fender above tire using block to maintain the proper height. Fender should be approximately 5" above tire to allow for suspension movement (See Fig. 1). A maximum width of 48" from center of the truck to the outside edge of the fender should be maintained (See Fig. 2).
3. Place fender bracket weldments [Part No. 10H74] on fender. Position the brackets to avoid any mounting obstacles on hoist and/or truck chassis.



FENDER ASSEMBLY, SINGLE AXLE

Aluminum (10H93) / Steel (11H13)


INSTALLATION INSTRUCTIONS (continued)


4. Mark mounting holes through the fender bracket weldment onto the fender. Remove the bracket and drill 7/16" dia. Holes in fender (See FIG. 3).
5. Attach fender bracket weldments to fender using fasteners provided.
6. Weld mounting plates [Part No. 21H37] to fender tubes [Part No. 21H61].
7. Position fender tubes with mount plates on hoist mainframe; align with fender bracket weldments. (**NOTE:** Fender tube length may need to be modified to fit specific application.)
8. Weld fender tube to hoist mainframe. If attaching the fender tubes to the truck chassis, an additional mount plate may need to be fabricated so the assembly can be bolted to the truck chassis.
9. Attach fender bracket weldment [Part No. 10H74] to mounting plate [Part No. 21H37] using fasteners provided (See FIG. 3).

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	4	10H74	FENDER BRACKET WDMT.	8.05
2	4	21H37	MOUNTING PLATE	1.09
3	4	21H42	RUBBER SPACER	.85
4	4	21H61	FENDER TUBE	1.26
5	32	00P34	3/8-16 UNC LOCKING NUT	.02
6	48	00771	3/8 DIA. FLAT WASHER	.05
7	16	00P78	3/8 DIA. NYLON WASHER	-
8	16	00P44	3/8-16 UNC X 1-1/2 HHCS	.07
9	16	01P21	3/8-16 UNC X 2-1/2 HHCS	.09
10	2		FENDER	
		90P24	FENDER - ALUMINUM	19.00
		90P25	FENDER - STEEL	35.00
ALUMINUM FENDER TOTAL				87.80
STEEL FENDER TOTAL				119.80

ADDITIONAL NOTES:


Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.





SWAPLOADER®


U.S.A. LTD.



ROLLER & ROLLER MOUNT (10H90 & 10H91)

INSTALLATION INSTRUCTIONS


1. Review all directions and diagrams provided before starting the roller and roller mount installation.
2. Locate position for roller mount brackets [Part No. 32H03] between cross sills of the container. Rollers should be positioned as far back and as wide as possible for stability. For hoist and folding bumper clearance, do not place brackets any closer than 11" to the subframe longsill (See Fig.1). Also, the roller axle center line should be approximately 1-11/16" below the bottom of the subframe longsill for roller clearance (See Fig. 1).




ROLLER & ROLLER MOUNT (10H90 & 10H91)


INSTALLATION INSTRUCTIONS (continued)

3. Some modification to the roller mount bracket may be required for the roller mount to fit properly. If the existing container cross members are wider than 6", a fabricated support member of 1/2" plate or thicker will need to be added (See Fig. 2).
4. Once the mount brackets are located on the container, weld the roller mount brackets in place (See Fig. 1).
5. Install the roller [Part No. 10H12] between the brackets with the roller axle [Part No. 10H31] and the fasteners provided (See Fig. 3). Grease the rollers before use.



MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT. Lb. PER EA.
1	4	32H03	ROLLER EAR	11.95
2	2	10H12	ROLLER WDMT.	39.78
3	2	10H31	ROLLER AXLE WDMT.	7.28
4	2	00P62	3/8-16 UNC X 1 BOLT	.05
5	2	90P03	1/8 NPT GREASE ZERK	.01
6	2	00755	3/8 DIA. LOCK WASHER	.01
7	2	00P38	3/8 DIA. WASHER H.T.	.10
TOTAL				142.28





FENDER ASSEMBLY, SINGLE AXLE

Steel (11H52)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting fender installation.
2. Center fender above tire using blocks to maintain the proper height. Fender height should be 3" to 4" above tire to allow for suspension movement (See Fig. 1). A maximum width of 45-1/2" from center of the truck to the outside edge of the fender should be maintained (See Fig. 2).
3. Place fender bracket weldments [Part No. 11H50] on fender. Position the brackets to avoid any mounting obstacle on hoist and/or truck chassis.




FIG. 1




FIG. 2

FENDER ASSEMBLY, SINGLE AXLE Steel (11H52)


INSTALLATION INSTRUCTIONS (continued)


4. Mark mounting holes through the fender bracket weldment onto the fender. Remove the bracket and drill 7/16" dia. holes in fender.
5. Attach fender bracket weldments to fender using fasteners provided.
6. Position fender mount weldment [Part No. 11H51] on hoist mainframe; align with fender bracket weldment. Mark mounting holes through the fender bracket weldment onto the fender mount weldment. Drill 7/16" dia. holes in fender mount weldment.
7. Weld fender mount weldment to hoist mainframe.
8. Weld guide gussets [Part No. 22H15] inside Z-channel of hoist mainframe (See Fig. 3), two guide gussets per fender mount weldment.

MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT. B. PER EA.
1	4	11H50	FENDER BRACKET WDMT.	6.98
2	4	11H51	FENDER MOUNT WDMT.	2.41
3	8	22H15	GUIDE GUSSET	.36
4	4	22H81	RUBBER SPACER	.77
5	12	00P77	3/8-16 X 3 HHCS	.18
6	12	00P78	3/8 DIA. NYLON WASHER	-
7	28	00771	3/8 DIA. FLAT WASHER	.05
8	28	00P34	3/8-16 LOCKING HEX NUT	.10
9	16	00P62	3/8-16 X 1 HHCS	.12
10	2	11H48	FENDER, STEEL TREAD PLATE	30.26
TOTAL				111.52

9. Attach fender bracket weldment [Part No. 10H50] to fender mount weldment [Part No. 11H51] using fasteners provided (See Fig. 3).


ADDITIONAL NOTE:
Prior to any welding, consult the truck manufacturer for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be connected as close as possible to the part being welded to avoid the possibility of arcing across bearings, gears, etc.





SWAPLOADER®


U.S.A. LTD.



CAB GUARD ASSEMBLY (50H99)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting cab guard installation.
2. Position cab guard weldment [Part No. 50H95] on frame with sufficient clearance between cab and cab guard (See Fig. 1).
3. Determine location for mounting holes. Mounting holes should not be located within 2-3/8" of the truck frame edge (See Fig. 1). Drill 21/32" dia. mount holes through cab guard channels.





CAB GUARD ASSEMBLY (50H99)

INSTALLATION INSTRUCTIONS (continued)

4. Mark mounting holes through the cab guard weldment onto truck frame. Remove cab guard weldment and drill $21/32"$ dia. holes in truck frame.
5. Attach cab guard weldment to truck frame using fasteners provided (See Fig. 2).


MATERIAL LIST				
ITEM	QTY	P/N	DESCRIPTION	WT. lb. PER EA.
1	1	50H95	CAB GUARD WDMT.	295.36
2	4	00P69	5/8-11 X 2 HHCS	.33
3	4	00P55	5/8-11 LOCKING HEX NUT	.18
4	4	00785	5/8 DIA. WASHER HT.	.08
TOTAL				292.72





SWAPLOADER[®]

U.S.A. LTD.





REAR LIGHT BAR ASSEMBLY (51H68)

REAR LIGHT BAR ASSEMBLY

((51H68))

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting rear light bar installation.
2. Trim truck frame to indicated dimensions (See Fig. 1). This step may have already been preformed if a bumper was previously installed.
3. Position center plate [Part No. 63H08] on the rear of the main frame. Weld center plate to truck frame (See Fig. 2 & Additional Notes).
4. Position stub light bar weldment [Part No. 51H69] on truck frame. Stub light bar weldment should be as high and as far back as possible on the truck frame to avoid interference with the bumper and fenders. It may be necessary to modify the stub light bar weldment to avoid interference. Drill mounting holes as required and mount using fasteners provided (See Fig. 3).
5. Attach the tail light module to the stub light bar weldments with the fasteners provided (See Fig 3).
6. Mount the identification light bar at top center of the center plate [Part No. 63H08] using the fasteners provided (See Fig. 3).
7. Mount license lamp right of the license plate (See Fig. 2) using the fasteners provided (See Fig. 3).



REAR LIGHT BAR ASSEMBLY

((51H68))

8. Mount junction box on the back left side of center plate (See Fig. 2), using the fasteners provided (See Fig. 3).
9. Route all wire harnesses into the junction box. Wire harnesses must enter the junction box through a compression fitting (Based on the size of the wire harness, choose a compression fitting with an appropriately sized grommet). Make wiring connections in junction box with wire harness from truck cab as indicated on wiring diagram (See Fig.4).

MATERIAL LIST

ITEM	QTY.	P/N	DESCR.	WT. - LB. PER EACH
1	2	51H69	STUB LIGHT BAR MOUNT.	7.87
2	ONE	63H08	CENTER PLATE	27.33
3	6	00P44	3/8-16 x 1 1/2 HHCS	0.07
4	6	00P34	3/8-16 LOCKING HEX NUT	0.02
5	6	00771	3/8 DIA FLAT WASHER	0.01
6	4	01P18	5/8-11 x 3 HHCS	0.35
7	8	00P81	#8-32 x 1 RND HD SCR	-
8	8	00P82	#8-32 HEX NUT	-
9	8	00P83	#8 LOCK WASHER	-
10	ONE	40P26	LIGHT KIT ASSEMBLY	23.00
11	REF	40P27	LEFT TAIL LIGHT MODULE WITH HARNESS	-
12	REF	40P28	RIGHT TAIL LIGHT MODULE WITH HARNESS	-
13	REF	40P29	SIDE MARKER LAMP	-
14	REF	40P30	STOP, TURN, & TAIL LAMP	-
15	REF	40P31	BACK-UP LAMP	-
16	REF	40P32	LICENSE LAMP ASSEMBLY (WITHOUT HARNESS)	-
17	REF	40P33	LICENSE LAMP	-
18	REF	40P34	LICENSE LAMP HARNESS	-
19	REF	40P35	IDENTIFICATION LIGHT BAR RAIL	-
20	REF	40P36	ID LIGHT BAR LAMP	-
21	REF	40P37	ID LIGHT BAR HARNESS	-
22	REF	40P38	JUNCTION BOX ASSEMBLY	-
TOTAL				68.07

ADDITIONAL NOTES:

Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.





FIG. 3



SWAPLOADER®

1800 N.E. Broadway Ave., Box D, Des Moines, Iowa 50316-0386
Phone/Fax (515) 266-3042 Toll Free 888-767-8000 swapldr@ncrns.net

U.S.A. LTD.

GROUND TO CHASSIS

JUNCTION BOX

WIRE HARNESS FROM TRUCK CAB

DRIVER SIDE LIGHT MODULE

PASSANGER SIDE LIGHT MODULE

IDENTIFICATION LIGHT BAR ASSEMBLY

LICENSE PLATE LAMP ASSEMBLY

TAN/CLEARANCE
BLACK/BROWN

GROUND WHITE

RT. TURN/STOP GREEN

BACK-UP RED

LT. TURN/STOP YELLOW

GROUND WHITE






Fig. 4



REAR BUMPER ASSEMBLY (52H11)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation.
2. Trim truck frame to indicated dimensions (See Fig. 1). These dimensions will facilitate the mounting of the rear light assembly if it is also being mounted.
3. Measure the distance from the bottom of the truck frame to the ground (NOTE: This should be performed on a level surface). Based this measurement and the dimensions in Fig. 1, the vertical channel [P/N: 63H94] may need to be modified in length to meet the Office of Motor Carrier Safety (OMCS) regulations. Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Fig. 2). Once the length has been determined for the vertical channels, weld them to the truck frame (See additional notes on next page).
4. Center the bumper weldment [P/N: 52H12] on the vertical channels [P/N: 63H94]. Position rear of bumper from rear of the hoist as indicated by the bumper location chart. This is crucial in order to ensure that the container longills do not contact the bumper during the dump cycle (See Fig. 1 & 2).




BUMPER LOCATION CHART								
DIM. A	DIM B. (Max)							
	SL-95	SL-145	SL-180	SL-220/222 & SL-240	SL-2418	SL-330 & SL-400	SL-375/405 & SL-505/545	SL-650
24 5/8"	13 1/2	15 3/4	15 1/4	17	14 1/4	14	16 1/2	19 1/4
22 5/8"	12 1/4	14 1/2	14	15 3/4	13	12 3/4	15	
20 5/8"	11	13	12 3/4	14 1/4	11 3/4			
18 5/8"	9 3/4	11 3/4	11 1/2					

REAR BUMPER ASSEMBLY (52H11)

INSTALLATION INSTRUCTIONS (continued)

5. Weld the bumper weldment to the vertical channels (See Fig. 1 & 3).




ADDITIONAL NOTES:

1. Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. All welds should be done utilizing a low hydrogen welding process.


MATERIAL LIST

ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	1	52H12	REAR BUMPER WDMT	95.66
2	2	63H94	VERTICAL CHANNEL	9.58
TOTAL				114.82



1800 NE Broadway Avenue, Des Moines, Iowa, U.S.A. 50313-2644
 Phone: (515) 266-3042 • Fax: (515) 313-4426 • Toll Free: (888) 767-8000
 E-Mail: sales@swaploader.net • Web Site: www.swaploader.com


01FEB06



REAR BUMPER ASS'Y w/ EXTENSIONS (52H11 with 52H13 Extensions)

INSTALLATION INSTRUCTIONS

1. Review all directions and diagrams provided before starting bumper installation.
2. Trim truck frame to indicated dimensions (See Fig. 1). These dimensions will facilitate the mounting of the rear light assembly if it is also being mounted.
3. Measure the distance from the bottom of the truck frame to the ground (NOTE: This should be performed on a level surface). Based this measurement and the dimensions in Fig. 1, the vertical channel [P/N: 63H94] may need to be modified in length to meet the Office of Motor Carrier Safety (OMCS) regulations. Regulation 393.86 requires that no bumper be located more than 30" off the ground when the truck is empty, and the end of the bumper should not be located more than 24" from the extreme rear of the vehicle, including truck bodies (See Fig. 2). Once the length has been determined for the vertical channels, weld them to the truck frame (See additional notes on next page).
4. Center the bumper weldment [P/N: 52H12] with factory installed extensions [P/N: 52H13] on the vertical channels [P/N: 63H94]. Position rear of bumper from rear of the hoist as indicated by the bumper location chart. This is crucial in order to ensure that the container longills do not contact the bumper during the dump cycle (See Fig. 1 & 2).



BUMPER LOCATION CHART								
DIM. A	DIM B. (Max)							
	SL-95	SL-145	SL-180	SL-220/222 & SL-240	SL-2418	SL-330 & SL-400	SL-375/405 & SL-505/545	SL-650
24 5/8"	19 3/4	22 1/2	21 3/4	25 1/4	21 3/4	21 1/2 *	24 1/4 *	27 1/4
22 5/8"	18 1/2	21	20 1/2	23 3/4	20 1/2	20 *	22 3/4 *	
20 5/8"	17 1/4	19 1/2	19 1/4	22 1/4	19 1/4			
18 5/8"	16	18 1/4	18					


* Dimensions assume 6" tall longills. For 8" tall longills add 2 1/4" to the dimension shown.

REAR BUMPER ASS'Y w/ EXTENSIONS

(52H11 with 52H13 Extensions)

INSTALLATION INSTRUCTIONS (continued)

5. Weld the bumper weldment to the vertical channels (See Fig. 1 & 3).




ADDITIONAL NOTES:

1. Prior to any welding, consult the truck manufacture for any special precautions that may need to be taken. Typically the batteries must be disconnected and the ground lead from the welder should be as close to the part being welded to avoid the possibility of arcing across bearings, gears, etc.
2. All welds should be done utilizing a low hydrogen welding process.

MATERIAL LIST

ITEM	QTY	P/N	DESCRIPTION	WT lb. PER EA.
1	1	52H12	REAR BUMPER WDMT	95.66
2	2	63H94	VERTICAL CHANNEL	9.58
3	1	52H13	REAR BUMPER EXTENSIONS	58.42
TOTAL				173.24



1800 NE Broadway Avenue, Des Moines, Iowa, U.S.A. 50313-2644
Phone: (515) 266-3042 • Fax: (515) 313-4426 • Toll Free: (888) 767-8000
E-Mail: sales@swaploader.net • Web Site: www.swaploader.com

01FEB06

PREDELIVERY CHECK LIST
SWAPLOADER U.S.A., LTD.

Conducted By: _____
Dealer: _____
Customer: _____

Date: _____

I. RECORD THE FOLLOWING INFORMATION:

SwapLoader Hoist: Model No.: _____
 Serial No.: _____

Truck Chassis: Identification No.: _____
 GVW: _____
 CA (Cab to Axle): _____
 Distance From Center Line of Rear Axle to
 Rear of Hoist: _____

PTO: Make: _____
 Model: _____
 Serial No.: _____
 % of Engine RPM: _____

Hydraulic Pump: Make: _____
 Model: _____
 Serial No.: _____

II. INSTALLATION TO CHASSIS

Were there any problems bolting the hoist to the truck chassis with the
parts provided? ☐ Yes ☐ No
If yes, please describe _____

☐ All bolts checked for proper tightness.

☐ Please include photos of the hoist installed on the truck chassis.
Be sure to include at least one photo from each side.

III. CONTROLS

☐ Controls easy to reach from diver's seat.
☐ Movement of controls correct per installation instructions.

PREDELIVERY CHECK LIST
Page 2

IV. HYDRAULICS INSTALLATION

☐ Correct hydraulic oil level in reservoir

☐ Check for leaks

Any abnormal noise during operation: ☐ Yes ☐ No

If yes, explain: _____

WITH ENGINE OPERATING @ 1000 RPM, RECORD THE FOLLOWING INFORMATION:

Cycle time for dump mode:

Up _____ Sec. Down _____ Sec.

Cycle time for load/unload mode:

Unload _____ Sec. Load _____ Sec.

Filter pressure _____ PSI

Main pressure, controls in neutral _____ PSI

Main relief pressure _____ PSI

V. OPERATION

☐ Jib operates freely in both directions

☐ Jib cannot be extended or retracted when raised in dump position or when pivot joint is tilted in unload position.

Both safety hooks are fully engaged when jib is extended.

☐ Parts and operators manuals in cab.

☐ Lubricate sliding jib and all grease zerks per installation instructions.

VI. DECAL

☐ All safety decals and product decals installed per Drawing 11H20.

ADDITION COMMENTS:

Send completed form to:

SwapLoader U.S.A., Ltd.
1800 NE Broadway Avenue
Des Moines, IA 50313

Retain one copy for your file.

OPERATION

OPERATING INSTRUCTIONS

During all operations of the SwapLoader, the speed of the engine should be maintained at 1,000 to 1,200 RPM, assuming the ratio of the Power Take Off is about 100%.

Depress the clutch and, after 2 seconds, switch on the P.T.O.. Then, smoothly release the clutch: the pump should be running.

LOADING A CONTAINER

- 1 - Retract the jib (right control backward). Then, tilt the arm backward (left control backward).
- 2 - Move the truck backwards until the hook engages the curved bar of the container. **NEVER EXTEND THE JIB** to reach the proper catching height, rather tilt the arm.
- 3 - Tilt the arm forward (left control forward), making sure the curved bar is securely attached to the hook. Release the brakes of the truck and steer to get the truck correctly aligned with the container. Watch the container rails which must come to rest centered on the rear rollers. Do not extend the jib during lifting.
- 4 - When the container is resting on the frame, move the jib forward all the way to ensure the container is locked on (right control forward). Disengage the P.T.O..

DUMPING

- 1 - Again move the jib forward (right control forward) to ensure that the container is locked.
- 2 - Extend the main lift cylinders (left control backward). **DO NOT RETRACT THE JIB WHILE DUMPING.** Retracting the jib during dumping may unlock the mechanical jib latches which could allow the container to crash down onto the hoist and/or abruptly unload.

PLACING A CONTAINER ON THE GROUND

- 1 - Move the sliding jib all the way back (right control backward) until mechanical jib latches unlock.
- 2 - Tilt the arm backwards (left control backward). When the container touches the ground, release the brakes to free the truck for forward movement caused by the container.

WARNING:

- 1 - DON'T OVERSPEED THE PUMP - 1,500 RPM MAXIMUM.
- 2 - DON'T DUMP ON UNEVEN GROUND.
- 3 - DON'T DRIVE WITH THE CONTAINER IN THE DUMPED POSITION OR WITH THE HOOK TILTED BACK.



HOIST PROP OPERATING INSTRUCTIONS

RAISING PROP

1. Unload all cargo from body.
2. Raise hoist and stand prop in upright position.
3. Lower hoist until hoist rests on top of prop.



- WARNING:**
- 1 - Do not power hoist down onto prop.
 - 2 - Make sure prop is inserted into retaining pocket on hoist (see Dwg. No. 50H23).
 - 3 - Do not attempt to use prop to support the hoist with a loaded container.

LOWERING PROP

1. Raise hoist and lower prop until it sets on the prop rest.



- WARNING:** If the prop is not in perfect working order, it must be repaired before using.

MAINTENANCE

**WEEKLY SERVICE
(50 OPERATIONS)**

1. Lubricate with grease
 - Lifting hook on jib
 - Jib slide - top, bottom, and side guides
2. Check hydraulic oil level
3. Check hydraulic hose and fittings for leaks. Also check hydraulic hose for wear. Repair and/or retighten as necessary.

**MONTHLY SERVICE
(200 OPERATIONS)**

1. Lubricate with grease
 - Fittings on air lift cylinders (quantity: 4)
 - Front pins on rear pivot joint weldment (quantity: 2)
 - Fittings on rear pivot and rollers (quantity: 4)
2. Check all bolts and retighten as required.
3. Check adjustments on safety lock mechanism.

YEARLY SERVICE

1. Change hydraulic oil, replace hydraulic filter element, and wash out suction strainer.
2. Check main relief valve setting.

HYDRAULIC OIL SPECIFICATIONS

Type: High Pressure (Anti-Wear) Hydraulic
ISO Viscosity Grade: 46 Viscosity,
SUS at 100 Degree F: 194-236

AMOCO

AMOCO AW 46

Keystone

KLC-5

ARCO

Duro AW 46

Lubriplate

HO-1

Chevron

AW Hydraulic Oil 46

Mobil

DTE 25

Cities Service

AW Hydraulic Oil 46

Phillips

Magnus A Oil 46

Conoco

Super Hydraulic Oil 46

Shell

Tellus 46

Exxon

Nuto H 46

Sun

Sun Vis 747 (821 WR)

Gulf

Harmony 46 AW

Texaco

Rando Oil HD 46



Kendall

Kenoil R & O AW-46

Union

Unax AW 46

PARTS LIST




SL-95 HOIST FINAL ASS'Y

SL-95

DWG.-11H15 ~ REV. B

SL-95 HOIST FINAL ASSEMBLY DWG.-11H15					REVISION B
ITEM	QTY.	P/N	DESCR.	WT.- LB. PER EACH	REMARKS
1	ONE	11H17	TELESCOPIC JIB SUB-ASS'Y	475.80	
2	ONE	11H18	PIVOT JOINT SUB-ASS'Y	330.59	
3	ONE	11H19	MAINFRAME SUB-ASS'Y	584.56	
4	ONE	90H25	FINAL HYD ASS'Y	176.51	NOT SHOWN
5	ONE	11H20	DECAL ASS'Y	-	NOT SHOWN
6	ONE	11H21	PARTS & OPER. MANUAL	-	
7	ONE	90P42	SERIAL TAG	.01	
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
				1567.47	TOTAL

C:\2-CUMMINS\1-1119 06/23/00 15:35




MAINFRAME SUB-ASSEMBLY

SL-95

DWG.-111H19 ~ REV C

MAINFRAME SUB-ASSEMBLY DWG.-11H19					REVISION C
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS
1	ONE	11H58	MAINFRAME WDMT	329.38	
2	2	11H09	MAINFRAME PIN WDMT	3.76	
3					
4	8	22H38	FRONT BRACKET	1.72	
5	2	22H39	REAR BRACKET	2.10	
6	6	90P71	12" WEAR BLOCK	.71	
7	ONE	11H91	JIB LOCK VALVE MOUNT	2.49	
8	2	20P29	HYD CYL 4" X 38	109.00	
9	28	00755	3/8" LOCK WASHER	.01	
10	2	00P36	3/8" FLAT WASHER HT	.01	F-436
11	24	00P14	3/8-16 HEX NUT	.02	GR-8
12	4	00P13	3/8-16 X 1 1/4 HHCS	.06	GR-8
13	24	00P68	3/8-16 X 1 1/4 FL HD SCR	.03	BRASS
14	22	00784	1/2" FLAT WASHER HT	.02	F-436
15	22	00P35	1/2-13 LOCKING HEX NUT	.06	GR-C
16	22	00P15	1/2-13 X 1 3/4 HHCS	.15	GR-8
17	ONE	01P20	3/8-16 x 1 3/4 SOC HD SCR	.07	GR-8
18	2	01P08	5/16-18 x 2 HHCS	.05	GR-8
19	2	00752	5/16" LOCK WASHER	.01	
20					
21					
22					
				595.89	TOTAL



NOTE:


WDMT 11H93 TO BE USED
WITH S/N A00709 & HIGHER.
WDMT 11H62 TO BE USED
WITH S/N A00708 & LOWER

PIVOT JOINT SUB-ASSEMBLY



SL-95

DWG.-11H18 ~ REV C

PIVOT JOINT SUB-ASSEMBLY DWG.-11H18					REVISION C
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS
1					
2	ONE	11H93	PIVOT JOINT WDMT	251.90	
3	2	11H04	ROLLER ASS'Y	34.98	
4	2	11H08	PIVOT PIN WDMT	4.33	
5	2	11H10	MAIN PIVOT PIN WDMT	9.81	
6					
7	2	22H35	ROLLER RETAINER	.52	
8	2	22H36	ROLLER RETAINER BOLT	.16	
9	2	22H37	PIVOT PIN CAP	.51	
10	4	00P36	3/8 ϕ FLAT WASHER HT	.05	F-436
11	4	00755	3/8 ϕ LOCK WASHER	.05	
12					
13	4	00P62	3/8-16 x 1 HHCS	.12	GR-8
14					
15	2	00P73	1/2-13 x 1 1/4 FL HD SOC SCR	.11	GR-8
17	2	00767	5/8 ϕ LOCK WASHER	.08	
18	2	90P03	1/8 NPT ZERK STR	.01	
19	2	90P05	1/8 NPT ZERK 45'	.01	
20	2	90P20	1/4-28 ZERK STR	.01	
21					
22					
				353.76	TOTAL



TELESCOPIC JIB SUB-ASSEMBLY DWG.-11H17					REVISION B
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS
1	ONE	10H08	1Ø CYLINDER PIN	1.75	
2	ONE	10H94	JIB WDMT	184.41	
3	ONE	10H96	OUTER TUBE WDMT	174.95	
4	ONE	11H11	SAFETY LATCH ASS'Y	37.49	
5	ONE	62H11	JIB COVER PLATE	.94	
6	2	20H19	CYLINDER RETAINER	.60	
7	2	20H21	SPACER	.20	
8	ONE	20H65	CLAMP LINER	.21	
9	ONE	22H27	WEAR BLOCK	.14	
10	ONE	22H28	CLAMP BAR	7.43	
11	ONE	22H29	CYLINDER PIN	2.59	
12	2	60H27	1 1/2Ø PIN WASHER	.16	
13	ONE	20P30	HYD CYL 2 1/2Ø X 24	61.00	
14	8	00P18	5/16-18 x 1 FL HD SCR	.01	BRASS
15	4	00755	3/8Ø LOCK WASHER	.01	
16	2	00P03	3/8-16 x 3/4 HHCS	.04	GR-8
17	2	00P62	3/8-16 x 1 HHCS	.05	GR-8
18	4	00P32	3/8-16 x 1 1/4 SOC HD SCR	.06	GR-8
19	2	00P80	3/4-10 x 5 HHCS	.81	GR-8
20	2	00P17	3/4-10 HEX NUT	.20	GR-8
21	2	00P72	3/4-10 LOCKING HEX NUT	.20	GR-C
22	ONE	00P05	EXT RET RING FOR 1Ø	.01	
				475.80	TOTAL





SAFETY LATCH ASSEMBLY

SL-95

DWG.-11H11 ~ REV B



SAFETY LATCH ASSEMBLY DWG.-11H11					REVISION 8
ITEM	QTY.	P/N	DESCR.	WT.- lb. PER EACH	REMARKS
1	2	10H35	TAKE UP WDMT	.25	
2	2	00P85	5/8-11 x 3 1/2 HHCS	.46	CR-8
3	2	11H02	SAFETY LATCH WDMT	5.54	
4	ONE	11H03	CONN BAR WDMT	9.29	
5	2	20H69	RELEASE LEVER	4.98	
6	2	20H93	LATCH STOP	.10	
7	4	22H02	PIVOT SUPPORT	.92	
8	4	00P14	3/8-16 HEX NUT	.02	CR-8
9	2	00P22	3/4 x 2 1/2 CLV PIN	.33	
10	4	00P23	1/4 x 1 3/4 CLV PIN	.03	
11	2	00P24	5/8-11 HEX NUT	.09	CR-8
12	4	00P25	1/16 x 3/4 COTTER PIN	-	
13	4	00P26	1/8 x 1 COTTER PIN	.01	
14	2	00P27	1/8 x 1 1/4 COTTER PIN	.01	
15	2	00P28	EXT RET RING FOR 3/4	.01	
16	2	90P04	7/8 x 6 SPRING	.38	
17	4	00772	1/2 x 1/2 FLAT WASHER	.04	
18					
19					
20					
21					
22					
				37.67	TOTAL




MANUAL CONTROL ASSEMBLY

DWG.-90H64

MANUAL CONTROL ASSEMBLY DWG.-90H64					REVISION	
ITEM	QTY.	P/N	DESCR.	WT.- lb. PER EACH	REMARKS	
1	ONE	10H51	VALVE MOUNT BRACKET	8.24		
2	ONE	20P39	HYD VALVE ASS'Y	27.00		
3	2	20P08	REMOTE VALVE CONTROL HANDLE	2.80		
4	ONE	20P09	CONTROL HANDLE MOUNT CONSOLE	4.05		
5	2	20P10	BONNET CONNECTION KIT	.50		
6	2	20P15	CONTROL CABLE 84" LG	1.75		
7	4	00755	3/8" LOCK WASHER	.05		
8	4	00P13	3/8-16 x 1 1/4 HHCS	.13	CR-8	
9	4	00P14	3/8-16 HEX NUT	.10	CR-8	
10	3	00P19	5/16-18 x 2 3/4 HHCS	.13	CR-8	
11	3	00P20	5/16-18 HEX NUT	.09	CR-8	
12	3	00752	5/16" LOCK WASHER	.04		
13						
14						
15						
16						
17						
18						
19						
20						
21						
22						
				51.29	TOTAL	



SECTION A-A




SECTION B-B

FINAL HYDRAULIC ASSEMBLY

SL-95

DWG.-90H25 ~ REV G

FINAL HYDRAULIC ASSEMBLY DWG.-90H25					REVISION 6	
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS	
1	ONE	90H27	HYD SUB-ASS'Y	30.95	NOT SHOWN	
			CYL CIRCUIT			
2	ONE	90H26	HYD SUB-ASS'Y	15.33	NOT SHOWN	
			PUMP CIRCUIT			
3	ONE	90H64	MANUAL CONTROL ASS'Y	51.29	NOT SHOWN	
4	ONE	20P31	HYD PUMP, GEAR	18.00	NOT SHOWN	
5	ONE	20P05	HYD TANK	54.20		
6	ONE	20P22	HYD FILTER	2.30		
7	ONE	21P28	HYD VALVE	2.20		
8	ONE	10P26	ADP, HYD PIPE NIPPLE	.70		
9	4	00P15	1/2-13 x 1 3/4 HHCS	.23	GR-8	
10	4	00P35	1/2-13 LOCKING HEX NUT	.05	GR-C	
11	4	00784	1/2" FLAT WASHER HT	.04	F-436	
12	2	10P28	HEX BOLT 5/16" x 1 1/4	.03	HEX-T2	
13	2	10P29	COVER PLATE	.10	TCP-T2	
14	2	10P30	CLAMP HALF ASS'Y	.04	T2050	
15	ONE	20P64	INDICATOR GAUGE	.01		
16						
17						
18						
19						
20						
				175.36	TOTAL	




HYD SUB-ASS'Y - CYL CIRCUIT

SL-95


DWG. - 90H27 ~ REV E

HYD SUB-ASS'Y - CYL CIRCUIT DWG. - 90H27					REVISION #
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS
1	4	10P49	HOSE ASS'Y 1/2 HP X 26	1.45	
2	ONE	12P82	HOSE ASS'Y 3/8 HP X 19	1.09	
3	ONE	11P09	HYD TUBING - FRONT LOWER	2.11	
4	ONE	11P10	HYD TUBING - FRONT UPPER	2.19	
5	ONE	11P11	HYD TUBING - VALVE LOWER	2.57	
6	ONE	11P12	HYD TUBING - VALVE UPPER	2.66	
7	ONE	12P83	HOSE ASS'Y 3/8 HP X 59	2.83	
8	ONE	12P84	HOSE ASS'Y 3/8 HP X 79	3.00	
9	ONE	12P85	ADP, HYD FMJC SWIVEL / MJIC 45'	.30	
10	ONE	90H47	NYLON HOSE SLEEVE, 1 1/2"	.30	
11	6	11P23	ADP, HYD MJIC / O-RING 90'	.30	6801-8
12	2	12P17	ADP, HYD O-RING PORT RED.	.16	6410-10-8
13					
14	2	10P42	ADP, HYD M JIC BHD BRANCH TEE	.30	2703-LN-8
15	2	10P43	ADP, HYD M JIC BHD UNION	.30	2700-LN-8
16	3	10P44	ADP, HYD M JIC / FM JC SWIVEL 90'	.30	6500-8
17	ONE	10P45	ADP, HYD MJIC / O-RING 90'	.30	6801-8-10
18	2	12P16	ADP, HYD M JIC / O-RING 90' EXT	.37	6801-LL-8
19	ONE	11P08	ADP, HYD MJIC / O-RING STR	.30	6400-8-10
20	2	12P14	ADP, HYD MJIC / MP 45'	.20	2503-6-6
21	2	11P35	ADP, HYD O-RING / FP STR	.30	6405-8-6
22					
TOTAL				29.71	TOTAL




HYD SUB-ASS'Y - PUMP CIRCUIT
SL-95
DWG.-90H26 ~ REV B

HYD SUB-ASS'Y - PUMP CIRCUIT DWG. - 90H26					REVISION B	
ITEM	QTY.	P/N	DESCR.	WT. - LB. PER EACH	REMARKS	
1	ONE	12P29	HOSE 3/4 LP X 24	.88		
2	ONE	12P28	HOSE 1 LP X 120	6.60		
3	ONE	10P61	HOSE ASS'Y 1/2 HP X 106	4.42		
4	ONE	12P18	ADP, HYD HOSE INSERT/ O-RING	.38	4604-16	
5	ONE	10P32	ADP, HYD MJIC / ORB 45°	.30	6802-10-12	
6	ONE	12P20	ADP, HYD MP/ FP RED. BUSH.	.30	1 1/4 x 1	
7	ONE	12P21	ADP, HYD MP/ FP RED. BUSH.	.18	1 x 3/4	
8	ONE	10P35	ADP, HYD MJIC / O-RING STR	.30	6400-10-12	
9	ONE	12P23	ADP, HYD HOSE INS./ ORB 90°	.58	4601-12	
10	ONE	10P37	ADP, HYD MJIC / MP 90°	.30	2501-4-4	
11	ONE	10P38	ADP, HYD JC CAP	.10	304-C-4	
12						
13	2	10P21	1 1/2" T-BOLT CLAMP	.10	TBC 150	
14	ONE	12P19	ADP, HYD HOSE INSERT/ MP	.30	ST10	
15	ONE	12P22	ADP, HYD HOSE INSERT/ MP	.31	ST5	
16	2	11P20	WORM GEAR CLAMP	.10	HSS16	
17						
18						
19						
20						
21						
22						
				15.35	TOTAL	



RIGHT SIDE



LEFT SIDE





DECAL ASSEMBLY

SL-95

DWG.-11H20 ~ REV A

DECAL ASSEMBLY DWG. - 11H20					REVISION A	
ITEM	QTY.	P/N	DESCR.	WT. - lb. PER EACH	REMARKS	
1	2	90P07	OPR & SERV MANUAL			
2	2	90P08	HOIST - BODY SPEC.			
3	ONE	90P09	HYD OIL SPEC			
4	ONE	90P10	HYD OIL FLAMMABLE			
5	2	90P11	HOIST FALLING			
6	ONE	90P12	LEVER CONTROL			
7	ONE	90P13	SAFTY INST			
8	3	90P14	SWAPLOADER - JB			
9	ONE	90P18	RELIEF VALVE			
10	4	90P22	SL-95			
11						
12						
13						
14						
15						
16						
17						
18						
19						
20						
21						
22						
					TOTAL	

OPTIONS




PROP FINAL ASSEMBLY

SL-95

DWG.-11H25 REV B

PROP FINAL ASSEMBLY DWG.-11H25					REVISION 8
ITEM	QTY.	P/N	DESCR.	WT.- lb. PER EACH	REMARKS
1	ONE	11H22	CENTER PROP WDMT	26.36	
2	ONE	11H23	PROP SHAFT WDMT	7.40	
3	ONE	11H24	PROP MODIFICATION WDMT	5.64	
4	ONE	21H57	CRANK STOP	.14	
5	ONE	22H62	BUSHING	.28	
6	ONE	22H63	PROP CRADLE	.48	
7	2	00P08	3/8-16 x 3/4 SOC SET SCR	.02	
8	ONE	00P74	14-20 x 1 3/4 HHCS	.08	GR-8
9	ONE	00P51	1/4-20 LOCKING HEX NUT	.07	GR-C
10	ONE	90P52	PROP DECAL	-	
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
				40.49	TOTAL



SWAPLOADER®

U.S.A. LTD.

1800 NE Broadway Avenue, Des Moines, Iowa, U.S.A. 50313-2644
Phone: (515) 266-3042 • Fax: (515) 313-4426 • Toll Free: (888) 767-8000
E-Mail: sales@swaploader.net • Web Site: www.swaploader.com